

Samsung GALAXY S[®] III

User Guide



Table of Contents

Get Started.....	1
Your Phone at a Glance	1
Set Up Your Phone.....	1
Install the battery	1
Charge the Battery	2
Turn your Phone On	2
Activation and Service	3
Get Your Numbers	3
Get Activated.....	3
Finalize Your Activation.....	3
Manage Your Account.....	4
Re-Boost®	4
Complete the Setup	5
Set Up Voicemail	6
Memory Card	6
Install a microSD Card	6
Remove a microSD Card	7
View microSD Card Memory	7
Format a microSD Card	7
Unmount a microSD Card	7
Phone Basics	8
Your Phone's Layout	8
Key Functions.....	8
Turn Your Phone On and Off.....	9
Turn Your Screen On and Off.....	9
Touchscreen Navigation.....	11
Multi Window	17
Your Home Screen	19
Creating Shortcuts.....	19
Adding and Removing Primary Shortcuts	20

Adding and Removing Widgets	20
Extended Home Screens	20
Recent Apps	21
Status Bar	21
Enter Text	22
Touchscreen Keyboards	22
Text Input Methods.....	23
Google Voice Typing	23
Samsung Keyboard.....	24
Swype.....	25
Tips for Editing Text	25
Phone Calls.....	27
Make Phone Calls.....	27
Call Using the Keypad.....	27
Call from Logs	27
Call from Contacts.....	27
Call a Number in a Text Message	28
Call a Number in an Email Message	28
Call Emergency Numbers	28
Enhanced 911 (E911) Information	29
Receive Phone Calls	29
Answer an Incoming Call.....	29
Mute the Ringing Sound	29
Reject an Incoming Call	29
Voicemail	30
Retrieve Voicemail Messages	30
Voicemail Notification	30
Visual Voicemail	30
Phone Call Options.....	30
Dialing Options	31
Caller ID	31
Call Waiting	31
3-Way Calling	32

Call Forwarding	32
In-call Options	33
Speed Dialing	33
Logs	34
View Logs	34
Logs Options	34
Clear Logs	35
Contacts	36
Get Started with Contacts	36
Access Contacts	36
Add a Contact	36
Save a Phone Number	37
Edit a Contact	37
Add or Edit Information for a Contact	38
Assign an Image to a Contact	38
Assign a Ringtone to a Contact	38
Link a Contact	39
Delete a Contact	39
Add Contacts to Your Favorites	39
Create Groups	39
Create a New Group	40
Add a Contact to a Group	40
Send a Message to Group Members	40
Share a Contact	41
Accounts and Messaging	42
Google	42
Create a Google Account	42
Access Gmail	42
Send a Gmail Message	43
Read and Reply to Gmail Messages	43
Email	44
Add an Email Account	44
Add a Microsoft Exchange ActiveSync Account	44

Compose and Send Email.....	45
View and Reply to Email	46
Manage Your Email Inbox	46
Edit Email Settings	47
Delete an Email Account	50
Text and Multimedia Messaging	50
Send a Message	51
New Messages Notification	51
Managing Message Conversations	51
Messaging Settings	53
Social Networking Accounts	55
Flipboard	55
Google+	56
Hangouts	56
YouTube	56
Apps and Entertainment	57
Samsung Link	57
Configure Samsung Link Settings	58
Use Samsung Link to Share Media with Another Device	58
Group Play	59
DivX	60
DivX Legal Information	60
Locating Your VOD Registration Number	60
Register Your DivX Device for VOD Playback of Purchased Movies	60
Google Play Store.....	61
Find and Install an App.....	61
Create a Google Wallet Account	62
Open an Installed App.....	62
Uninstall an App	62
Google Play Books	63
Google Play Magazines.....	63
Google Play Movies & TV	63
Google Play Music.....	63

Music App	63
Google Maps	64
Web and Data	65
Internet	65
Chrome	65
Data Services (3G and 4G)	65
Your Data Services User Name	65
4G Services	66
Wi-Fi	66
Turn Wi-Fi On and Connect to a Wireless Network	66
Bluetooth	67
Turn Bluetooth On or Off	68
Connect a Bluetooth Headset or Car Kit	68
Reconnect a Headset or Car Kit.....	69
Disconnect or Unpair from a Bluetooth Device	69
Send Information Using Bluetooth.....	69
Receive Information Using Bluetooth	71
Virtual Private Networks (VPN).....	71
Prepare Your Phone for VPN Connection	71
Add a VPN.....	72
Connect to a VPN.....	72
Pictures and Video	73
Camera	73
Take Pictures	73
Picture Options.....	73
Record Videos.....	76
Video Options.....	77
Gallery	78
View Photos and Videos	79
Zoom In or Out on a Photo.....	80
Working with Photos.....	80
Share Photos and Videos.....	81
Video App	83

Paper Artist.....	83
G+ Photos.....	84
Tools and Calendar.....	85
Calculator.....	85
Calendar	85
Add an Event to the Calendar	85
View Events.....	86
Erase Events	86
Clock.....	87
Downloads.....	87
Dropbox	87
Download the Desktop Application.....	88
Access Dropbox on your Phone	88
Manually Upload a Picture to Dropbox.....	88
Flipboard.....	89
Google Search.....	89
Help	89
My Files	89
S Memo	90
Create a New S Memo	91
S Suggest	92
S Voice	92
Voice Recorder	93
VPN Client	93
Wallet.....	93
Settings.....	94
Wi-Fi Settings	94
Turn Wi-Fi On or Off.....	94
Configure Wi-Fi Settings	94
Other Wi-Fi Settings	95
Wi-Fi Direct.....	96
Bluetooth Settings.....	96
Turn Bluetooth On or Off	96

Configure Bluetooth Settings.....	97
Data Usage Settings.....	98
More Networks Settings.....	98
Airplane Mode	99
Mobile Networks	99
VPN	99
NFC Settings	100
Turn NFC On or Off.....	100
Android Beam.....	100
S Beam Settings	100
Turn S Beam On or Off.....	101
Nearby Devices	101
Screen Mirroring Settings	102
Lock Screen.....	102
Screen Lock	102
Lock Screen Options	103
Display Settings	105
Wallpaper	105
Notification Panel	105
Multi Window	106
Page Buddy	106
Brightness	107
Auto Rotate Screen	107
Screen Timeout.....	107
Daydream.....	107
Font Style	108
Font Size	108
Touch Key Light Duration	108
Display Battery Percentage.....	108
Auto Adjust Screen Tone	109
LED Indicator Settings	109
Sound Settings	109
Volume	109

Vibration Intensity	110
Ringtones	110
Vibrations	110
Default Notification Sound	111
Vibrate When Ringing	111
Dialing Keypad Tone	111
Touch Sounds	111
Screen Lock Sound	111
Haptic Feedback	112
Auto Haptic.....	112
Emergency Tone	112
Samsung Keyboard Settings.....	112
HDMI Audio Output	112
Home Screen Mode Settings.....	113
Call Settings.....	113
Call Rejection	113
Set Up Call Rejection Messages	114
Answering/Ending Calls	114
Turn Off Screen During Calls	114
Call Alerts	114
Call Accessories	115
Ringtones and Keypad Tones	115
Personalize Call Sound	116
Noise Reduction	116
Increase Volume In Pocket	116
US Dialing	116
International Dialing.....	117
TTY Mode.....	117
DTMF Tones	117
DDTM	117
Voicemail Settings.....	118
Blocking Mode Settings	118
Hands-free Mode Settings	119

Power Saving Mode Settings.....	119
Accessory Settings	120
Accessibility Settings	120
Language and Input Settings.....	122
Choose a Default Language.....	122
Set a Default Input Method.....	122
Google Voice Typing Settings	122
Samsung Keyboard.....	122
Swype Settings.....	124
Voice Search Settings	125
Text-to-Speech Options	126
Pointer Speed.....	126
Motion Settings	127
Smart Screen Settings.....	128
Smart Stay.....	128
Smart Rotation	128
Voice Control Settings	129
Accounts Settings	129
Add an Account	129
Backup Options	129
Location Services Settings	130
Security Settings.....	131
Passwords.....	131
Device Administration.....	132
Security Update Service.....	132
Credential Storage	132
Application Manager Settings.....	133
Battery Settings	133
Storage Settings	133
Date and Time Settings	134
Activate This Device	134
System Update Settings	135
About Device Settings	135


Copyright Information.....	137
Index	138

Get Started

The following topics give you all the information you need to set up your phone the first time.

Your Phone at a Glance

The following illustration outlines your phone's primary external features and buttons.




Set Up Your Phone

You must first install and charge the battery to begin setting up your phone.

Install the battery

Install the battery in the phone.

1. Using the slot provided, gently lift the cover.
2. Insert the battery, making sure to align the gold contacts on the battery with the gold contacts in the phone.
3. Replace the cover, making sure all the tabs are secure and there are no gaps.



Note: When you insert the battery, your phone may power on automatically.

Charge the Battery

After you install the battery, charge it before using your phone.

Note: Your phone's battery should have enough charge for the phone to turn on and find a signal, run the setup application, set up voicemail, and make a call. You should fully charge the battery as soon as possible.

1. Plug the USB cable into the charger/accessory jack on the bottom of the phone.
2. Plug the USB cable into the charging head, and then plug the charging head into an electrical outlet.



Turn your Phone On

Use the Power/Lock Key to turn your phone on, to lock the screen or display the lock screen, and to access the Device options menu.

- Press the **Power/Lock Key** to turn the phone on.

- If your phone is activated, it will turn on, search for service, and begin the setup application.
- If your phone is not yet activated, see [Activate Your Phone](#) for more information.



Activation and Service

Before using your device, you must set up your service with Boost Mobile. You will need your phone's serial number (MEID), printed on a sticker inside the battery compartment.

Get Your Numbers

You will need the phone's MEID (DEC) number to activate your phone. The MEID (DEC) can be located on the box that the phone came in or on the back of the phone in the battery compartment. The MEID is an 18-digit number.

Get Activated

Go to boostmobile.com/activate or activate by phone at **1-888-BOOST-4U**.

Note: During the activation process you can choose to get a new number or use an existing number.

Finalize Your Activation

You'll receive a message from Boost letting you know that your phone number and account are ready to go.

Manage Your Account

Access information about your account. You can:

Note: Be sure to remember the 4-digit Account PIN you set up during activation. You'll need to enter your Account PIN when you log in to 'My Account' or anytime you call Boost about your account. If you forget your Account PIN, you will need to remember the month and year you activated your phone.

From Your Phone

Access your account from the special Boost Zone app.

- Press  and then tap  **Apps** >  **Boost Zone**.

From Your Computer

- Log in with your phone number and account PIN at boostmobile.com.

Call Us

- Call Boost Customer Care by dialing **1-888-BOOST-4U** (1-888-266-7848) from a landline or another phone.

Re-Boost[®]

Sign up for Auto Pay to keep your service working month after month. Or, you can buy Re-Boost cards at thousands of retailers and add money to your account from your phone or by logging in at boostmobile.com.

Pick How You Want To Pay

Boost Mobile makes it easy to add money to your account. You decide exactly how and where you want to pay. Keep your account active by using your phone and adding money to your account.

Pay With Cash

Find an Authorized Re-Boost Retailer near you. Pick up a Re-Boost Card or recharge for as low as \$10 at the register, where available.

Pay Anytime With A Credit/Debit Card

Dial #ADD (#233) to add money from your phone or visit 'My Account' at boostmobile.com to do it online. Securely register your credit/debit card with Boost for more convenient one-time payments or to set up easy Auto Re-BoostSM payments.

Set Up Worry-Free Payments With Auto Re-BoostSM

It's the easiest way to make sure your account stays on and active. Use a credit card, debit card or bank account – whatever's best for you.

Visit boostmobile.com/reboost to get the details on all your Re-Boost options.

Complete the Setup

After you activate your phone, follow the prompts to set up your Google account and preferences.

For best results, activate your phone before starting the setup process.

Note: During setup, you may see a notice about **Connections Optimizer**. Connections Optimizer helps you manage and enhance your data experience by finding and connected to remembered Wi-Fi networks on your device, and if applicable, the 4G network. For more information, see [Mobile Networks](#).

1. After you activate your phone, you'll see the Welcome screen. Choose a language, and then tap **Start** to begin setup.
2. Follow the onscreen instructions to complete each section. For each topic, you will have an option to skip it and continue to the next screen.
 - **Got Google?:** Follow the prompts to sign in to your current Google Account, or sign up for a new Google Account right from your phone.
 - Tap **Yes** to enter your Gmail address and password and then tap the right arrow to sign in to your current Google Account.
 - Tap **No** to sign up for a new Google account. Tap **Get an account**, and then follow prompts to set up your new account.
 - **Backup and Restore:** Select your Google account backup settings. If you're signing in with an existing Google account, you can choose to restore your Google account information, such as apps, bookmarks, Wi-Fi passwords, and contacts, to your new phone. You can also choose to keep your new phone backed up with your Google account.
 - **Google & location:** Select options for allowing Google and other apps to use your location information.
 - **This phone belongs to:** Enter your name. Your phone uses your name to personalize some features.
 - **Google services:** Learn about Google's privacy policy and other terms.

3. At the **Setup complete** screen, tap **Finish** to complete setup and continue with other options.
4. At the Dropbox screen, select an option and follow the onscreen instructions.
 - **Create a new Dropbox account:** Tap to set up a Dropbox account to save your photos and videos to a Web-based storage area.
 - **I already have an account:** Tap to sign in to your current Dropbox account.
 - **No thanks:** Tap to skip the Dropbox setup screens.
5. That's it, your phone is now ready to use.

Set Up Voicemail

You should set up your Voicemail and personal greeting as soon as your phone is activated.

Note: Always use a password to protect against unauthorized access. Your phone automatically transfers all unanswered calls to your voicemail, even if your phone is in use or turned off.

1. Press  and then tap  **Phone**.
2. Touch and hold  to dial your voicemail.
3. Follow the system prompts to:
 - Create your password.
 - Record your name announcement.
 - Record your greeting.

Note: You can also access Visual Voicemail by touching .

Memory Card

You can install an optional microSD™ memory card (not included), to add storage for images, videos, music, documents, and other files on your phone.

Install a microSD Card

Use the following procedures to install an optional memory card (not included) in your phone.

1. Using the slot provided, gently lift the cover off the phone.
2. Insert the card with the gold contacts facing down.
3. Firmly press the card into the slot and make sure that it locks into place.

Remove a microSD Card

Use the following procedures to remove an optional installed memory card (not included) from your phone.

1. Using the slot provided, gently lift the cover off the phone.
2. Firmly press the card into the slot to release the lock. The card should pop partially out of the slot.
3. Remove the card from the slot.
4. Replace the battery cover.

Important: You can easily damage the memory card and its adapter by improper operation. Please be careful when inserting, removing, or handling it. Do not over-insert the card as this can damage the contact pins.

View microSD Card Memory

Use the following procedure to view used and available memory on an optional installed memory card (not included).

See [Device Memory](#) for more information.

- Press  and tap  > **Settings** > **More** > **Storage**.

Format a microSD Card

Formatting permanently removes all files stored on an optional installed memory card (not included).

Note: The formatting procedure erases all the data on an installed card, after which the files cannot be retrieved. To prevent the loss of important data, please check the contents before you format a card.

1. Press  and tap  > **Settings** > **More** > **Storage**.
2. Tap **Format SD card** > **Format SD card** > **Delete all**.

Unmount a microSD Card

When you need to remove an optional installed memory card, you must unmount the card first to prevent corrupting the data stored on it or damaging the card.


1. Press  and tap  > **Settings** > **More** > **Storage**.
2. Tap **Unmount SD card**, and then tap **OK**.

Phone Basics

Your phone is packed with features that simplify your life and expand your ability to stay connected to the people and information that are important to you. The following topics will introduce the basic functions and features of your phone.

Your Phone's Layout

The following illustrations outline your phone's basic layout.



Key Functions

The following list defines the features listed in the above illustrations.

- **LED indicator** glows or blinks in different colors to show status when the screen is turned off. The LED glows red when charging, and blinks red when the battery is low; blinks blue when a notification has arrived, or when you are recording voice; and glows green when the battery is fully charged and the phone is attached to a charger.
- **Earpiece** lets you hear the caller and automated prompts during calls.
- **Proximity and Light Sensors** detect the presence of objects near the phone, and light conditions.
- **Front Camera** allows you to take pictures and videos of yourself.

- **Power/Lock Key** lets you turn the phone on or off, turn the screen on or off, or lock the screen. Press and hold for a Device options menu, where you can turn the phone off or restart it, or for easy access to Airplane mode, and to Mute, Vibrate, and Sound modes.
- **Back Key** lets you return to the previous screen, or close a dialog box, options menu, the Notifications panel, or onscreen keyboard.
- **Home Key** returns you to the Home screen. Press and hold to see recent apps, and access Task Manager and Google Now.
- **Menu Key** allows you to access a menu from most of your phone's screens.
- **Volume Key** adjusts the volume of your phone's sounds. From the Home screen, press to adjust master volume. During calls or playback, press to adjust volume. Press to mute the ringtone of an incoming call.
- **Camera** lets you take pictures and record videos.
- **Flash** helps illuminate subjects in low-light environments when the camera is focusing and capturing a photo or video.
- **Microphones** allow other callers to hear you when you are using the speakerphone, and captures sound during recording.
- **3.5 mm Headset Jack** allows you to plug in the included headset, or other optional headset, for convenient, hands-free conversations and music playback.
- **Speaker** plays ringtones and sounds. The speaker also lets you hear the caller's voice in speakerphone mode.
- **USB Charger/Accessory Port** allows you to connect the phone charger/USB cable (included) and other optional accessories (not included).

CAUTION: Inserting an accessory into the incorrect jack may damage the phone.

Turn Your Phone On and Off

The instructions below explain how to turn your phone on and off.

- Press and hold the  **Power/Lock Key**.

Your screen remains blank while your phone is off (unless the battery is charging).

Turn Your Screen On and Off

Your phone allows you to quickly turn the screen off when not in use and to turn it back on and unlock it when you need it.

Turn the Screen Off When Not in Use

- To quickly turn the screen off, press the  **Power/Lock Key**.

To save battery power, the phone automatically turns off the screen after a certain period of time when you leave it idle. You will still be able to receive messages and calls while the phone's screen is off.

Note: For information on how to adjust the time before the screen turns off, see [Screen Timeout](#).

Turn the Screen On and Unlock It

1. To turn the screen on, press the  **Power/Lock Key**.
2. Swipe the screen in any direction to unlock the screen.
 - If you have set up a screen lock, you will be prompted to draw the pattern or enter the password or PIN. See [Screen Lock](#).

Touchscreen Navigation

Your phone's touchscreen lets you control actions through a variety of touch gestures.


Tap

When you want to type using the onscreen keyboard, select items onscreen such as application and settings icons, or press onscreen buttons, simply tap them with your finger.



Touch and Hold

To open the available options for an item (for example, a contact or link in a Web page), touch and hold the item.



Swipe or Slide

To swipe or slide means to quickly drag your finger vertically or horizontally across the screen.




Drag

To drag, touch and hold your finger with some pressure before you start to move your finger. While dragging, do not release your finger until you have reached the target position.



Flick

Flicking the screen is similar to swiping, except that you need to swipe your finger in light, quick strokes. This finger gesture is always in a vertical direction, such as when flicking the contacts or message list.



Rotate

For most screens, you can automatically change the screen orientation from portrait to landscape by turning the phone sideways. When entering text, you can turn the phone sideways to bring up a bigger keyboard.



Note: The Auto rotate option must be enabled for the screen orientation to automatically change. To make this selection, press  >  > **Settings** and tap **My device** > **Display** > **Auto rotate screen**. See [Auto rotate screen](#) for more information.

Pinch and Spread

"Pinch" the screen using your thumb and forefinger to zoom out or "spread" the screen to zoom in when viewing a picture or a Web page. (Move fingers inward to zoom out and outward to zoom in.)



Tip: Pinching any Home screen will let you see thumbnails of all seven Home screens. Tap a thumbnail to go straight to another Home screen.

Multi Window

Multi Window allows you to use two apps on the same screen, in separate, resizable windows.

Enable Multi Window

Enable Multi window in the Display settings.

1. Press  and then tap  > **Settings** > **My device** > **Display**.
2. Tap the check box beside **Multi window** to enable or disable the option.

Display Multi Window

After you enable Multi window in Display settings, you can control whether Multi window displays on the screen, for easy access to its features.

When Multi Window is enabled, it displays on the left side of the screen by default. You can drag the tab along the side of the screen, or tap the tab to open Multi Window, and then drag Multi window to the other side of the screen.

- Touch and hold the  **Back Key**.

Work With Multi Window

After enabling Multi Window, you can use it to run two apps at the same time. You can launch apps from Multi window, or drag an app to the screen to run multiple apps at the same time.

The apps display together on a split screen. You can switch between the apps, or adjust the size of their display on the screen.

Use Multi Window to Launch Multiple Apps

When you drag an app from Multi window on top of an open app, both apps display in a split window.

- While using one app, touch the tab to display Multi Window, and then touch and drag an app to the screen.

Note: To close an app in Multi Window, tap the X.

Adjust the Size of Apps in Multi Window

While using Multi Window, you can adjust the size of the two apps on the screen.

- Touch and drag the border between the windows.

Switch Multi Window App Positions

While using Multi Window, you can switch the position of the app windows on the screen.

- Touch the border between the windows, and then touch .

Make a Multi Window App Full Screen

While using Multi Window, you can expand an app to full screen anytime.

- Touch the border between the windows, and then touch .

Your Home Screen

The home screen is the starting point for your phone's applications, functions, and menus. You can customize your home screen by adding application icons, shortcuts, folders, widgets, and more. Your home screen extends beyond the initial screen. Swipe the screen left or right to display additional screens.

Note: You can keep swiping in one direction and make it back to the main Home screen. The small circles toward the bottom of the screen let you know your current screen position.

Tip: Press  to return to the main home screen from any other screen.

Creating Shortcuts

Learn how to add, move, or remove items from the home screen.

Adding Items from the Applications Menu

1. Press , and then tap  **Apps**.
2. Touch and hold an application icon, and then drag it to a Home screen.
3. Release the screen to lock the new shortcut into its new position on the Home screen.

Adding Items from the Home screen

1. Press  to display the Home screen.
2. Touch and hold an empty area of the Home screen, and then choose **Apps and widgets**.
3. Touch and hold the application icon, and then drag it to a Home screen. Release the icon to lock it on the screen.

Removing a Shortcut

1. Press  to display the Home screen.
2. Touch and hold the desired shortcut, and then drag it to the Remove icon and release it. As you place the shortcut into the Trash, both items turn red.

Note: This action does not delete the application; it simply removes the shortcut from the Home screen.

Adding and Removing Primary Shortcuts

You can change any of your primary shortcuts with the exception of the Apps shortcut. The primary shortcuts are the bottom row of app shortcuts that remain static on all home screens (by default Phone, Contacts, Messaging, Internet, and Apps).

Note: Before replacing a primary shortcut, you must first add the replacement shortcut to the Home Screen. For more information, see [Creating Shortcuts](#).

1. Press  to display the Home screen.
2. Touch and hold the primary shortcut you want to replace and then drag it to an empty space on any Home screen.
3. Touch and hold a new shortcut on the Home screen, and then drag it to the empty space in the row of primary shortcuts.

Adding and Removing Widgets

Widgets are self-contained applications that reside either in your Widgets tab or on the main or extended Home screens. Unlike a shortcut, the Widget appears as an onscreen application. Widgets can include Contacts shortcuts, bookmarks, Facebook status windows, Gmail and email accounts, and many other types of apps.

Adding a Widget

1. Press  to display the Home screen.
2. Touch and hold an empty area of the Home screen, and then choose **Apps and widgets > Widgets**.
3. Touch and a widget, and then drag it to a Home screen. Release the widget to lock it on the screen.

Removing a Widget

1. Press  to display the Home screen.
2. Touch and hold the desired widget, and then drag it to the Remove icon. As you drop the widget into the Trash, both items turn red.

Note: This action does not delete the widget, it simply removes it from the current screen

Extended Home Screens

In addition to the main home screen, your phone has six extended home screens to provide more space for adding icons, widgets, and more. Touch and hold the icon or widget and then drag across the screen to move from the main screen to an extended screen.

There are six extended screens in addition to the main Home screen.

Note: You cannot add more screens, unless you have previously deleted any of the existing screens. The maximum number of home screens is seven.

To go directly to a particular screen:

1. From any home screen, pinch the screen to display thumbnail images of all screens.

- or -

Press  **Home**, and then tap  **Menu** > **Edit page**.

2. Tap the screen you want to open.

Recent Apps

You can access recently used applications through a display of shortcuts to the applications themselves.

1. Press and hold  **Home** from any screen to display Recent apps.
2. Tap an image to open the application.

Status Bar

The status bar at the top of the home screen provides phone and service status information on the right side and notification alerts on the left. To view notification alerts, touch and hold the status bar and drag it down.

Status Icons

Icon	Description
	Bluetooth® active
	Connected to another Bluetooth device
	Wi-Fi® active
	Vibrate
	Mute
	Speakerphone Active
	Network (full signal)
	3G (data service)
	4G (data service)

	Airplane Mode
	Alarm Set
	Smart stay is enabled, and you are using a feature that utilizes Smart stay.
	Battery (full charge shown)

Notification Icons

Icon	Description
	Missed call
	New email
	New Gmail
	New message
	New voicemail
	Event
	USB connection
	Updates available
	Downloading
	Keyboard active

Enter Text

You can type on your phone using the available touchscreen keyboards.

Touchscreen Keyboards

Touchscreen keyboard entry can be done in either Portrait or Landscape orientations. The Landscape orientation provides more space and results in slightly bigger onscreen keys. If you find that you prefer to enter text via the onscreen keyboard, and need bigger keys, use this orientation.

Selecting a Text Input Method

Some characters and types, such as some symbols and emoticons, are not accessible from the onscreen keyboard.

There are a couple of ways to select a text input method:

Settings Menu:

- Press  and tap  **Menu > Settings > My device > Language and input > Default** and select an input method.

Text Input field:

1. From a screen where you can enter text, touch and drag down the Notifications area.
2. Tap **Select input method** and select an available input method.

Text Input Methods

Your device offers several text input methods.

- **Google voice typing** allows you to speak your entries.
- **Samsung keyboard**: allows you to enter text by touching keys on a virtual QWERTY keyboard. Samsung keyboard includes optional predictive text, which matches your key touches to common words so you can select a word to insert it into your text.
- **Swype** lets you enter words by swiping across the virtual QWERTY keyboard. Instead of tapping each key, use your finger to trace over each letter of a word. You can also tap letters to enter words.

Select a Default Text Input Method

You can select a default Text Input Method from Settings, or choose on at any time while entering text.

From Settings:

- Press  and tap  **Menu > Settings > My device > Language and input > Default**.

While entering text:

1. From a screen where you can enter text, drag down from the top of the screen to open the Notifications panel.
2. Tap **Select input method**, and then choose a text entry method.

Google Voice Typing

This feature uses Google voice recognition to convert your spoken words into text.

Use Google Voice Typing to Enter Text

1. From a screen where you can enter text, drag down from the top of the screen to open the Notifications panel, and then tap **Select input method > Google voice typing**.
2. Speak into the microphone and watch your text being entered onscreen. If the text is incorrect, tap **DELETE**.

Note: Select a language by tapping at the bottom of the **Listening** area. Tap **Add more languages** to assign a new language via the Google voice typing menu. Removing the check mark from the **Automatic** field allows you to select additional languages.

Configure Google Voice Typing

Set Google Voice Typing options. For more information, see [Google Voice Typing](#).

- Press  and tap  > **Settings** > **My device** > **Language and input**, and then tap  next to **Google voice typing**.

Samsung Keyboard

With Samsung Keyboard, it's easy to enter text, symbols, and numbers.

Use Samsung Keyboard to Enter Text

1. From a screen where you can enter text drag down from the top of the screen to open the Notifications panel, and then tap **Select input method > Samsung keyboard**.
2. Tap keys to enter text. While entering text, use these options:
 - If you make a mistake, tap  to delete incorrect characters. Touch and hold  to delete a whole word or field.
 - Tap  to change the case of the text. Tap twice to switch to all capitals.
 - Tap  to switch to a symbols keyboard, to enter symbols. There are two symbol keyboards.
 - Tap  to switch to Google Voice typing, to enter text by speaking.

Configure Samsung Keyboard

You can configure options for Samsung keyboard. For more information, see [Samsung Keyboard](#).

- Press  and tap  > **Settings** > **My device** > **Language and input**, and then tap  next to **Samsung keyboard**.

Swype

Swype lets you enter words by tracing over the letters on the virtual QWERTY keyboard. Instead of tapping each key, use your finger to trace over each letter of a word. You can also tap letters to enter words.

Swype provides next-letter prediction and regional error correction, which can compensate for tapping the wrong keys on the virtual QWERTY keyboards.

Use Swype to Enter Text

1. From a screen where you can enter text drag down from the top of the screen to open the Notifications panel, and then tap **Select input method** > **Swype**.
2. Swipe your finger continuously over the letters to form a word. As you swipe over letters, words matching your pattern display at the top of the Swype keyboard. To enter a word, lift your finger, or tap a word at the top of the keyboard.
3. While entering text, use these options:
 - If you make a mistake, tap  to delete a single character. Touch and hold  to delete an entire word or field.
 - By default, Swype starts with a capital at the beginning of text. Tap  to start with a capital letter, or tap  twice to enter all capitals.
 - Tap  to switch to a symbols keyboard, and then tap keys to enter symbols.

Configure Swype

Choose Swype options. For more information, see [Swype Settings](#).



- Press  and tap  > **Settings** > **My device** > **Language and input**, and then tap  next to **Swype**.

Tips for Editing Text

These tips allow you to cut or copy selected text and paste it into a separate selected area.

1. In a text entry field, double-tap the text.
2. Touch and drag the sliders to highlight and select the desired text.

3. Tap an onscreen option from the Edit text menu bar. You can drag your finger along the menu bar to see all the options:

-  **Select all:** Highlights all the text in the field.
-  **Cut:** Removes the selected text and saves it to the clipboard.
-  **Copy:** Copies the selected text to the clipboard.
-  **Paste:** Insert the last copied or cut text into the current field.
-  **Clipboard:** Display the clipboard to choose previously cut or copied text

Phone Calls

Make and receive phone calls, and use other call-related features.

Make Phone Calls

There are several convenient ways to place calls from your phone.

Call Using the Keypad

The most “traditional” way to place a call is by using the phone’s dialer screen.

1. Press  and tap  **Phone**.
2. Tap the number keys on the keypad to enter the phone number. As you enter digits, Smart Dial searches for contacts that match. If you see the number you want to dial, tap it to select the number without entering the rest of the digits.
3. Tap  to call the number.
4. To end the call, tap .

Call from Logs

All incoming, outgoing and missed calls are recorded in the Call log. You can place a call to numbers or contacts that display in this area.

1. Press  and tap  **Phone**.
2. Tap the **Logs** tab. A list of recent calls displays. You can use these options:
 - For additional options, tap the name or number.
 - Drag your finger from left to right across the contact to place a call, or drag your finger from right to left to create a message addressed to the number.

Call from Contacts

You can place calls directly from Contacts.

Depending on your motion settings, you may also be able to place a call simply by lifting the phone to your ear. See [Motion Settings](#) for details.

1. Press  and tap  **Contacts**.

2. Use one of these methods:

- Tap the contact you want to call and then tap .
- Depending on your motion settings, you may also automatically call the displayed contact, simply by lifting the phone to your ear. See [Motion Settings](#) for details.
- Drag your finger from left to right across the contact to call their default number.

Tip: You can also swipe the entry from right to left to send a text message.

Call a Number in a Text Message

While viewing a text message, you can place a call to a number that is in the body of the message. For more information, see [Text Messaging and MMS](#).

1. Press  and tap  **Messaging**.
2. Open the message with the phone number and then tap the phone number.
3. Tap  to dial the number.

Tip: You can also call the number from a text or MMS message you received. Tap the name at the top of the conversation and then tap a phone number.

Call a Number in an Email Message

While viewing an email or Gmail message, you can place a call to a number that is in the body of the message.

1. Press  and tap  **Apps**, and then tap  or .
2. Open the message with the phone number and then tap the phone number.
3. The Phone app opens, displaying the phone number, ready for dialing. Tap  to place the call.

Call Emergency Numbers

You can place calls to 911 even if the phone's screen is locked or your account is restricted. The procedure is the same, whether accessing the Phone app from the Lock screen, or from an unlocked Home screen.

1. Press  and tap  **Phone**.
2. Tap    .

Enhanced 911 (E911) Information

This phone includes Global Positioning System which is used for E911 emergency location services, where available.

When you place an emergency 911 call, the GPS feature of your phone seeks information to calculate your approximate location. Depending on several variables, including availability and access to satellite signals, it may take up to 30 seconds to determine and report your approximate location.

Important: Always report your location to the 911 operator when placing an emergency call. Some designated emergency call takers, known as Public Safety Answering Points (PSAPs), may not be equipped to receive GPS location information from your phone.

Receive Phone Calls

When you receive a phone call from a contact, the Incoming call screen appears and displays the caller ID icon, name, and phone number of the calling party. When you receive a phone call from someone who is not stored in Contacts, only the default caller ID icon and phone number appear on the Incoming call screen.

Note: If your phone is turned off, all calls automatically go to voicemail.

Answer an Incoming Call

When a call comes in, the Incoming call screen displays options.

To answer a call:

- Touch and slide  to the right.

Mute the Ringing Sound

You can mute the ringtone without rejecting the call by doing either of the following.

- Press the volume button down.
- Place the phone face down on a level surface. See [Motion Settings](#) to display the settings required to mute incoming calls by turning over the phone.

Reject an Incoming Call

When a call comes in, you can reject the call and send the caller to voicemail, or reject the call with a text message.

To Reject a Call:

- Touch and slide  to the left.

To Reject a Call with a Text Message

- Touch and slide **Reject call with message**, and then select a message, or tap **Create new message** to compose a new text message.

Voicemail

Your phone automatically transfers all unanswered calls to your voicemail, even if your phone is in use or turned off. You should set up your voicemail and personal greeting as soon as your phone is activated. Always use a password to protect against unauthorized access.

For more information about setting up Voicemail, see [Set Up Voicemail](#).

Retrieve Voicemail Messages

You can access your voicemail by using the following process.

1. Press  and tap  **Phone**.
2. Touch and hold  to access voicemail, and follow the prompts to review voicemail.

Voicemail Notification

There are several ways your phone alerts you to a new message.

- By playing a ringtone.
- By displaying  in the Notifications area of the Status bar.

Note: Your phone accepts messages even when it is turned off. However, your phone notifies you of new messages only when it is turned on and you are in a service area. You can check your voicemail by dialing 1 + area code + your wireless phone number. When your voicemail answers, enter your password.

Visual Voicemail

Visual Voicemail gives you a quick and easy way to access your voicemail. Now you can find exactly the message you are looking for without having to listen to every voicemail message first. View voicemails by caller name and number, along with the length of time and priority level of the message.

- Press  and tap  **Apps** >  **Voicemail**.

Phone Call Options

Your phone application provides many useful features and options to help you make the most of your calling experience.

Dialing Options

There are several options available when entering a new number.

1. Press  and tap  **Phone**.
2. While dialing, tap  to display a list of options. Tap an option to select it.
 - **Send message** to send a text message to the entry.
 - **Add to Contacts** to add the entered number into your Contacts list. See [Add a Contact](#) for more information.
 - **Speed dial setting** to display the contacts assigned to numbers 2 through 100. The number 1 is reserved for Voicemail.
 - **Add 2 sec pause** to add a 2-second pause to the number you are dialing.
 - **Add wait** to add a pause to the calling sequence, to wait until you tap a key to continue.
 - **Call settings** to configure call settings. For more information, see [Call Settings](#).

Caller ID

Caller ID identifies a caller before you answer the phone by displaying the number of the incoming call. You can block Caller ID if you do not want your number displayed when you make a call. This block only lasts for one call; to permanently block your number, call Customer Service.

1. Press  and tap  **Phone**.
2. Tap  **P**  **MNO**  **PQRS**.
3. Enter a phone number and then tap .

Call Waiting

When you're on a call, Call Waiting alerts you to incoming calls by sounding a tone. Your phone's screen informs you that another call is coming in and displays the caller's phone number (if it is available).

To respond to an incoming call while you're on a call:

- Slide  to the right to put the first call on hold and answer the second call. To switch between calls, tap **Swap**.

3-Way Calling

With 3-Way Calling (also known as Conference calling), you can talk to two people at the same time. When using this feature, the normal airtime rates will be charged for each of the two calls.

1. Press  and tap  **Phone**.
2. Enter a number and tap .
3. Once you have established the connection, tap **Add call** and dial the second number. (This puts the first caller on hold and dials the second number.)
4. When you're connected to the second party, tap **Merge**.

If one of the people you called hangs up during your call, you and the remaining caller stay connected. If you initiated the call and are the first to hang up, all callers are disconnected.

5. To end the three-way call, tap .

Call Forwarding

Call Forwarding lets you forward all your incoming calls to another phone number – even when your phone is turned off. You can continue to make calls from your phone when you have activated Call Forwarding.

Note: You are charged a higher rate for calls you have forwarded.

Activate Call Forwarding

1. Press  and tap  **Phone**.
2. Tap    .
3. Enter the area code and phone number to which you want your calls forwarded.
4. Tap . A tone will play to confirm Call Forwarding.

Deactivate Call Forwarding

1. Press  and tap  **Phone**.
2. Tap     .

3. Tap . A message will display to confirm the removal of Call Forwarding.

In-call Options

While you're on a call, you will see a number of onscreen options. Tap an option to select it.

- **Add call:** displays the dialer so you can call another person.
- **Keypad:** displays the onscreen keypad, where you can enter numbers using DTMF (Dual Tone Multi-Frequency). This is especially helpful if you need to enter an access code or other information while on an active call.
- **End call:** Terminate the call.
- **Speaker:** Route the phone's audio either through the speaker or through the earpiece.

Warning: Because of higher volume levels, do not place the phone near your ear during speakerphone use.

- **Mute/Unmute:** Turn the onboard microphone either on or off.
- **Headset:** Connect to a Bluetooth headset.
- Touch  for more options:
 - **Contacts:** Go to your Contact list.
 - **Memo:** Write down a memo during a call.
 - **Message:** Send a message during a call.

Speed Dialing

You can assign a shortcut number to a phone number in your Contacts List for speed dialing. There are one hundred available numbered spaces. The number 1 is reserved for Voicemail.

Assign a Speed Dial

1. Press  and tap  **Phone**.
2. Tap  > **Speed dial setting**.
3. Tap an unused space and then select a contact to assign to the number. The selected contact number will display in the speed dial list.

Remove a Speed Dial

1. Press  and tap  **Phone**.

2. Tap  > **Speed dial setting**.
3. Touch and hold on a speed dial, and then select **Remove**.

Edit a Speed Dial

1. Press  and tap  **Phone**.
2. Tap  > **Speed dial setting**.
3. Tap  > **Change order**.
4. Tap the entry you want to move, and then tap an unassigned space. (For example, if you select an entry in space 12, and space 8 shows "Not assigned," you can tap space 8 to move the entry.)
5. Tap **Done** to save the change.

Make a Call Using a Speed Dial

1. Press  and tap  **Phone**.
2. Touch the speed dial digits, holding the last digit until the number dials.

Logs

The Logs tab of the Phone application lists all recent incoming, outgoing, and missed calls.

View Logs

The following procedures will guide you through viewing your call logs list.

1. Press  and tap  **Phone**.
2. Tap the **Logs** tab to display logs.
 - To change the Logs view, tap  > **View**. Tap **All calls**, **Missed calls**, **Dialed calls**, **Received calls**, or **Rejected calls** to filter the list.

Logs Options

The following procedures will guide you through accessing and understanding your call log options.

- To make a call from Logs, see [Call from Logs](#).

For additional options:

1. Press  and tap  **Phone**.

2. Tap the **Logs** tab to display logs.
3. Touch and hold a listing to display the options list.
 - **Copy to dialing screen:** Copy the phone number from the call record to the Phone screen.
 - **Add to contacts/View contact:** Save the phone number to create or update a contact, or view the contact record where this number is saved.
 - **Send number:** Send the phone number in a text message.
 - **Add to reject list:** Add the phone number to the list of numbers, to have calls from the number blocked.
 - **Delete:** Erase the call record from Logs

Clear Logs

Follow these steps to clear the Logs list.

1. Press  and tap  **Phone**.
2. Tap the **Logs** tab to display logs.
3. Tap  > **Delete**, and then follow the prompts to select entries to delete.

Contacts

The Contacts application lets you store and manage contacts from a variety of sources, including contacts you enter and save directly in your phone as well as contacts synchronized with your Google account, your PC, compatible email programs (including Exchange Server), and your Facebook friends.

Get Started with Contacts

Before using Contacts, it's best to learn a few basics.

Your phone automatically sorts the Contacts entries alphabetically. You can create a Google contact, a phone contact, or a Corporate (Microsoft Exchange ActiveSync) contact.

- **Phone** contacts are stored locally on the phone.

Note: If the phone is ever reset to its factory default parameters, locally stored contacts (phone contacts) can be lost.

- **Google** contacts are shared with your existing Google account and can also be imported to your phone after you have created a Google Mail account.
- **Microsoft Exchange ActiveSync** contacts are shared with a Microsoft Exchange account.

Access Contacts

You can access contacts from the Contacts app, or from the Phone app.

- Press  and tap  **Contacts**.

— or —

- Press  and tap  **Phone** > **Contacts** tab.

Add a Contact

You can add contacts directly from the Contacts application. Enter details such as name, phone numbers, email addresses, mailing addresses, and more.

1. Press  and tap  **Contacts**.
2. Tap  at the top of the screen.
3. If you have accounts set up on your phone, tap a storage account.

4. Touch contact fields to enter information.

- Tap  and assign an image to the new entry. You can choose a picture from Gallery, including tagged pictures, take a new picture with Camera, or use a memo from S Memo.
- Tap the **Name** field and use the onscreen keyboard to enter the full name. Tap  next to the Name field to display additional name fields.
- Tap the **Phone number** field, and then enter the phone number. Tap  to add another Phone number. Tap , and then choose a label for the number.
- Tap **Email** to enter an email address.
- Tap **Groups** to assign the contact to a group.
- Tap **Ringtone** to choose a ringtone to play for calls from the contact.
- Tap **Message alert** to choose a ringtone to play for new messages from the contact.
- Tap **Vibration pattern** to choose a vibration to play for new calls or messages from the contact.
- Tap **Add another field** to add new fields for the contact.

5. Tap **Save** to save the new contact.

Save a Phone Number

You can save a phone number to Contacts directly from the phone dial pad.

1. Press  and tap  **Phone**.
2. Enter a phone number using the keypad.
3. Tap **Add to Contacts**, and then choose **Create contact** or **Update existing**.
4. If you're creating a new contact, choose an account for the contact.
5. Continue entering contact information, if desired. See [Add a Contact](#).
6. Tap **Save** to save the contact.

Edit a Contact

Once you've added a contact, you can add or edit any of the information in the entry, assign a caller ID picture, customize with a unique ringtone, and more.

Add or Edit Information for a Contact

You can modify existing contact information to keep your information up-to-date.

1. Press  and tap  **Contacts**.
2. Tap a contact to display it, and then tap  > **Edit**.
3. Tap any field you want to change or add. See [Add a Contact](#).
4. Add or edit the information, and then tap **Save**.

Tip: You can also touch and hold the contact and then tap **Edit**.

Assign an Image to a Contact

Adding a picture or image to a contact entry creates a more personal and easily recognized entry. For example, when receiving a call from one of your contacts, the picture will display. You can add a picture, or use an S Memo.

1. Press  and tap  **Contacts**.
2. Tap a contact to display it, and then tap .
3. Choose an option:
 - Choose **Image** to select a picture from Gallery.
 - Choose **Pictures by people** to select a picture from Gallery that contains a tag for the contact.
 - Choose **Take Picture** to take a new picture.
 - Choose **S Memo** to assign an S Memo to the contact image.
4. Touch and drag along the sides of the blue border box to crop the image to the desired size.
5. Tap **Done**, and then tap **Save** to assign the image.

Assign a Ringtone to a Contact

You can assign a special ringtone to individual contacts for more personalization.

1. Press  and tap  **Contacts**.
2. Tap a contact to display it.

3. Tap **Ringtone**, and then tap a ringtone to select it (a sample plays), or tap **Add** to find new ringtones.

Link a Contact

When you have contacts from various sources (Gmail, phone, Facebook, etc.), you may have multiple similar entries for a single contact. Your phone's Contacts application lets you link multiple entries into a single contact.

1. Press  and tap  **Contacts**.
2. Tap a contact to display it, and then tap  > **Link contact**.
3. Tap another entry to link it to the original contact.

Note: You can link up to five contacts in a single entry.

Delete a Contact

You can delete a contact from the contacts details page.

1. Press  and tap  **Contacts**.
2. Tap a contact to display it, and then tap  > **Delete**.
3. Tap **OK**.

Tip: You can also touch and hold the contact and then tap **Delete**.

Add Contacts to Your Favorites

The Favorites tab is a listing that can help you quickly access your most used or preferred Contacts entries.

1. Press  and tap  **Contacts**.
2. Tap a contact to display it, and then tap the star on the contact record.

Note: Another method to add or remove an entry from your favorites is to tap the star icon on the Contact's details page (upper-right). Tap to add the entry to your favorites (star is lit), tap again to remove.

Create Groups

This feature allows you to add a new or existing contact to a call group. This group can be one of the already present groups (Family, Friends, or Work) or a user-created group.

Create a New Group

You can create new groups with unique ringtones and vibration patterns.

1. Press  and tap  **Contacts > Groups**.
2. Tap  > **Create**.
3. Enter information about the group:
 - Tap the **Group name** field and enter a name for the new group.
 - Tap **Group ringtone** and select a ringtone for the group.
 - Tap **Message alert** to choose a ringtone to play for new messages from group members.
 - Tap **Vibration pattern** and select a vibration pattern for the group.
 - Tap **Add member** and select a member or members to add to the new Group.
4. Tap **Done** when you are finished adding members, and then tap **Save**.

Add a Contact to a Group

You can add new members to a group from your Contacts.

1. Press  and tap  **Contacts > Groups**.
2. Tap a group to display it, and then tap .
3. From the list of contacts, tap the contact(s) you want to add. (A green check-mark appears next to the selected entries.)
4. Tap **Done** to add the contact to the group.

Send a Message to Group Members

You can send a message to all or selected members of a group.

1. Press  and tap  **Contacts > Groups**.
2. Tap an existing group and then tap  > **Send message**.
3. Select the recipients of the new message (indicated by a green checkmark) and then tap **Done**.
4. Type your message, and then tap .

Share a Contact

You can quickly share contacts using Bluetooth, Dropbox, Email, Gmail, messaging, or Wi-Fi Direct.

1. Press  and tap  **Contacts**.
2. Tap a contact to display it, and then tap  > **Share namecard via**.
3. Send the current contact information to an external recipient via one of the following:
 - **Bluetooth** Send the information via Bluetooth. See [Bluetooth](#) for information on pairing and sending via Bluetooth.
 - **Email:** Send the information as an email attachment. See [Compose and Send Email](#) for details on sending email.
 - **Gmail:** Send the information as a Gmail attachment. See [Send a Gmail Message](#) for details.
 - **Messaging:** Send the contact information as an MMS message attachment (vcf file). For more information about messaging, see [Text Messaging and MMS](#).
 - **Wi-Fi Direct:** Send the information via a phone-to-device connection.

Accounts and Messaging

Set up accounts on your phone, to synchronize information between your phone and accounts. Use your phone's messaging features to send text and multimedia messages.

Google

Many of your phone's applications, such as Gmail, Google Maps, Google Talk, and the Google Play Store, require a Google account. To use these applications, you must set up your Google account on your phone. Setting up your account on your phone syncs your phone and your online Google account.

Create a Google Account

If you do not already have a Google account, you can create one online or using your phone.

Note: You can also create and sign into your Google/Gmail account through your phone's Setup application.

Although you need a Gmail account to use certain features of your phone, such as Google Play, you do not need to use Gmail as the default account for your phone.

Create a Google Account Online

1. From a computer, launch a Web browser and navigate to www.google.com.
2. On the main page, click **Sign in > SIGN UP**.
3. Follow the onscreen prompts to create your free account.

Create a Google Account Using Your Phone

1. Press  and tap  > **Settings > Account**.
2. Tap **Add account > Google > New**.
3. Follow the onscreen prompts to create your free account.

Access Gmail

Below are procedures for accessing your Gmail account.

1. Press  and tap  **Apps >  Gmail**.
2. Do any of the following:

- **View more email messages:** If the Inbox is full, swipe your finger up the screen to view more messages and conversations.
- **Read a new email message:** Tap the unread message or the conversation with an unread message (just-arrived items display in bold).
- **Select messages and conversations:** Tap the box before the email or conversation.
- **View the Inbox of another Gmail account:** Tap **Inbox** at the top of the screen and then tap the inbox of the Gmail account you want to view.

Send a Gmail Message

Below are procedures for sending a Gmail.

1. Press  and tap  **Apps** >  **Gmail**.
2. From the Inbox, tap .
3. Enter the message recipient's email address in the **To** field. You can add multiple recipients.
4. Tap **Subject** and enter the email subject.
5. Tap **Compose email** and compose your email. To add a picture attachment, tap  > **Attach picture** or **Attach video**.

Note: To send a carbon copy (Cc) or a blind carbon copy (Bcc) of the current email to other recipients, tap  > **Add Cc/Bcc**.

6. To send the message, tap .
 - To save the current email as a draft, tap  > **Save draft**. To later view your draft email messages, from the Inbox, tap **Inbox** and then tap **Drafts**.
 - To delete the current email message, tap  > **Discard**.

Read and Reply to Gmail Messages

Below are procedures for reading and replying to Gmail messages.

1. Press  and tap  **Apps** >  **Gmail**.
2. Tap a message to display its contents.

Tip: You can also access new messages through the Notifications bar. When a new Gmail message arrives, you'll see the icon in the Notifications bar. Touch and hold the bar and slide it down to display notifications. Tap a message to display it.

3. Tap  to create a reply message.
4. From the menu at the top of the screen, tap **Reply**, **Reply all**, or **Forward**.
5. To send the message, tap .

Email

Use the Email application to send and receive email from your webmail or other accounts. You can also access your Exchange ActiveSync email on your phone.

Add an Email Account

Email allows you to send and receive email using various email services. You can also receive text message alerts when you receive an important email.

1. Press  and tap  **Apps** >  **Email**.
2. Enter your email address in the **Email address** field.
3. Enter your password in the **Password** field. To see your password as you enter it, tap **Show password**.
4. Tap **Next** to start automatic email setup. If you need to configure custom settings, tap **Manual setup** and then enter your settings. These may include mail type, user name, password, server, security type, etc.
5. Follow the onscreen prompts to configure options for the account.
6. Tap **Done** to complete setup.

Note: You can also add email accounts from Settings. Press  and tap  > **Settings** > **Accounts** > **Add account**

Add a Microsoft Exchange ActiveSync Account

The Email application also provides access to your Microsoft Exchange account from your phone. If your company uses Microsoft Exchange Server 2003, 2007, or 2010 as the corporate email system, you can use this email application to wirelessly synchronize your email, Contacts, and Task information directly with your company's Exchange server.

Use the following procedure to synchronize your phone with a corporate email account.

Note: You can set up multiple Microsoft Exchange ActiveSync accounts on your phone.

1. Press  and tap  **Apps** >  **Email**.
2. Enter your email address in the **Email address** field.
3. Enter your password in the **Password** field. To see your password as you enter it, tap **Show password**.
4. Tap **Next** to start automatic email setup. For systems that require custom settings, tap **Manual setup** and then enter your settings. You may need to consult your network administrator for this information:
 - **Domain\Username:** Enter your network domain and username, separated by “\”.
 - **Password:** Enter your network access password (case-sensitive).
 - **Exchange Server:** Enter your system’s Exchange server remote email address. Obtain this information from your company network administrator.
 - **Use secure connection (SSL):** Tap to place a checkmark in the box, if your system requires SSL encryption.
 - **Use client certification:** Tap to place a checkmark in the box, if your system requires certification.
5. Follow the onscreen prompts to configure options for the account.
6. Tap **Done** to complete setup.

Note: You can also add email accounts from Settings. Press  and tap  > **Settings** > **Accounts** > **Add account**

Compose and Send Email

Compose and send email using any account you have set up on your phone. Increase your productivity by attaching files such as pictures, videos, or documents to your email messages.

1. Press  and tap  **Apps** >  **Email**.
2. From the Inbox, tap .
3. Compose your message:
 - Tap the **To** field and enter the recipient’s email address. You can add multiple message recipients.
 - To send a carbon copy (Cc) or a blind carbon copy (Bcc) of the current email to other recipients, tap **Cc/Bcc**.

- Tap the **Subject** field and enter the email subject.
- Tap the text entry field and compose your email.
- To add an attachment, tap . Choose from the following: **My Files, Images, Take picture, Video, Record video, Audio, Record audio, S Memo, Calendar, Contacts, or Location.**

4. To send the message, tap .

View and Reply to Email

Reading and replying to email on your phone is as simple as on your computer.

1. Press  and tap  **Apps** >  **Email**.
2. On the email account Inbox, tap a message to view it, and then choose an option:
 - Tap  **Reply** to reply to the sender.
 - Tap  **Reply all** to reply to all the addresses in the original recipient list.
 - Tap  **Forward** to forward the message to new recipient(s).
3. Enter a message (if desired) and then tap .

Manage Your Email Inbox

The following procedures allow you to view, refresh, sort, and delete your email messages.

View Your Email Inbox

1. Press  and tap  **Apps** >  **Email**.
2. Tap the account name field (upper-left) to open the complete email account list page.
3. Select an email account and tap an email message.

Refresh an Email Account

Whatever your automatic synchronization settings are, you can also synchronize your sent and received email messages manually at any time.

1. Press  and tap  **Apps** >  **Email**.
2. Select an email account.

- If you are already in an email account, tap the account name field (upper-left) to open the complete email account list page.
- Select an available email account.

3. Tap  (Refresh).

Sort Email Messages

1. Press  and tap  **Apps** >  **Email**.
2. On the email account Inbox, tap  > **Sort by**.
3. Select from the options to sort email messages by date received (most recent or oldest), by sender, read/unread status, starred favorites, attachments, priority, subject, flag, request, meeting requests, or size. (Not all options are available for all email accounts.)

Delete an Email Message

1. Press  and tap  **Apps** >  **Email**.
2. On the email account Inbox, touch and hold the message you want to delete.
– or –
Tap the check boxes beside email you want to delete.
3. On the options menu, tap **Delete**. Tap **Delete** again to confirm.

Edit Email Settings

You can edit general preferences, which apply to all email accounts, or configure settings for specific email accounts, such as email address and password, name display and signature, frequency of retrieval, and more.

Note: Available settings depend on the type of email account.

Edit General Preferences

1. Press  and tap  **Apps** >  **Email**.
2. Tap  > **Settings**.
3. Under **General settings**, configure settings. Available settings depend on the type of email account, and may include:
 - **Display:** Choose how emails are shown in the email list, and when you open them.

- **Composing and sending:** Choose what functions are available while composing and sending emails.
- **Auto-advance:** Choose how the email list displays after you delete or move an email.
- **Confirm deletions:** Choose whether the phone prompts you to confirm the action when you mark emails for deletion.
- **Priority senders:** Maintain a list of email addresses to ensure that emails from the addresses receive priority handling.
- **Spam addresses:** Create a list of email addresses and domains, to block emails from these senders.
- **Rules for filtering:** Set filters and manage filtered email.

Edit Account Settings

You can edit settings for your individual email accounts, such as email address and password, name display and signature, frequency of retrieval, and more.

Note: Available settings depend on the type of email account.

1. Press  and tap  **Apps** >  **Email**.
2. Tap  > **Settings**, and then tap **Account settings** for the account you want to edit. Settings may include:
 - **Sync settings:** Tap to configure options for synchronizing your phone with your account:
 - **Sync Email:** When enabled, your phone maintains synchronization with your email account. The last synchronization is displayed.
 - **Sync schedule:** Set options for synchronizing your phone with your email account. Available when Sync Email is enabled.
 - **Period to sync Email:** Choose a period of time to maintain synchronization between your phone and email account.
 - **Size to retrieve emails:** Choose a maximum size for emails, for your phone to automatically retrieve during synchronization. For larger emails, your phone will prompt you to download the contents when you open them.
 - **Signature:** When On, a text signature is automatically added to emails you send. Tap the **ON/OFF** switch to turn signatures On or Off. After turning signatures On, tap **Signature** to edit the default text signature.

- **Out of office settings:** Configure options for automatic replies to emails when you are out of the office.
- **Default account:** Assign an account as the default email account for outgoing messages. When you launch an email from other apps, the email will automatically be from this account.
- **Password:** Update your account password to match the password set on your account.
- **Email notifications:** When enabled, an icon displays in the Status bar when you receive new emails.
- **Select ringtone:** Choose a ringtone to play for new email notifications.
- **Vibrate:** When enabled, vibration plays for new email notifications.
- **More settings:** Configure other options, including the account name, carbon copy and blind carbon copy, synchronization, and security options.
 - **Account name:** Enter a name to identify this email account.
 - **Your name:** Enter a name, to be shown to recipients in emails from this account.
 - **Always Cc/Bcc myself:** Choose options for sending a copy of emails you send to yourself, as a copy (Cc) or blind copy (Bcc).
 - **Forward with attachments:** Choose whether to automatically include attachments when forwarding an email.
 - **Show images:** Choose whether to automatically display embedded images in the body of an email.
 - **Auto download attachments:** Choose whether the phone automatically downloads email attachments when you are connected to Wi-Fi. You might use this option to control how and whether you use your plan's data services to download attachments.
 - **Auto resend times:** Choose the number of times the phone attempts to resend an email after a delivery failure.
 - **Folder sync settings:** Choose folders to synchronize between your phone and account.
 - **Period to sync Calendar:** Choose the period for synchronizing calendar events between your phone and account.
 - **Empty server trash:** Delete the contents of the trash folder on the account server.

- **In case of sync conflict:** Choose whether information from the server or phone has priority when there is a conflict.
- **Security options:** Configure advanced security options, including encryption.
- **Number of emails to load:** Choose the number of emails displayed at one time.
- **Sync Contacts:** Choose whether contacts are synchronized between your phone and the account.
- **Sync Calendar:** Choose whether calendar events are synchronized between your phone and the account.
- **Sync Task:** Choose whether emails are synchronized between your phone and the account.
- **Exchange server settings:** Configure the Domain\user name, Password, and other Exchange server settings.
- **Incoming settings:** Configure settings for the account server to access your account on your phone.
- **Outgoing settings:** Configure settings for accessing your account from your phone.

Delete an Email Account

If you no longer want an email account on your phone, you can delete it through the mail settings menu.

1. Press  and tap  **Apps** >  **Email**.
2. Tap  > **Settings** > **Account settings**.
3. Tap , and then tap account(s) to delete.
4. Tap **Delete**, and then follow the prompts to confirm the deletion.

Text and Multimedia Messaging

With Text Messaging (SMS), you can send and receive text messages between your phone and another phone that supports messaging.

Multimedia messages, (MMS), can contain text and pictures, recorded voice, audio or video files, picture slideshows, contact namecards (vCard), or calendar events (vCalendar).

See your service plan for applicable charges for messaging.

Send a Message

Quickly compose and sent text messages on your phone.

1. Press  and tap  **Apps** >  **Messaging**.
2. Tap  **Compose** to create a message:
 - Tap **Enter recipient** and enter a Contact name, a mobile phone number, or an email address using the onscreen keyboard. As you enter letters, possible matches from your accounts and contacts display on the screen. Touch a match to add it to the message.
 - Tap **Enter message** to enter your message.
 - Tap  to attach an image, picture, video, audio clip, S Memo, Calendar event, location info, or contact.
3. Tap  **Send** to send the message.

New Messages Notification

Depending on your notification settings, the phone will play a ringtone, vibrate, or display the message briefly in the status bar when you receive a new text or multimedia message. To change the notification for new text and multimedia messages, see [Text and MMS Options](#) for details.

A new message icon  also appears in the notifications area of the status bar to notify you of a new text or multimedia message. The Messaging application icon  also displays the number of new messages.

To open the message, touch and hold the status bar, and then slide the status bar down to open the Notifications panel. Tap the new message to open and read it. For information on reading and replying to messages, see [Managing Message Conversations](#).

Managing Message Conversations

Text and multimedia messages that are sent to and received from a contact (or a number) are grouped into conversations or message threads in the All messages screen. Threaded text or multimedia messages let you see exchanged messages (similar to a chat program) with a contact on the screen.

Read a Text Message

- On the Messaging screen, tap the text message or message thread to open and read it.

- If you have a new message notification, slide the status bar down to open the Notifications panel. Tap the new message to open and read it.

Note: To view the details of a particular message, in the message thread, touch and hold the message to open the options menu, and then tap **View message details**.

If a message contains a link to a Web page, tap the message and then tap the link to open it in the Web browser.

If a message contains a phone number, tap the message and then tap the phone number to dial the number or add it to your contacts.

View a Multimedia Message (MMS)

1. Press  and tap  **Apps** >  **Messaging**.
2. From the message list, tap a message to open its contents.
3. While the message is open, tap the play icon (on a video or audio file) to play back the file or tap an image to view a picture.
 - The file attachment on the MMS message can be saved to an optional installed memory card (not included). To save the attachment, touch and hold the file. Tap **Save attachment**. Select the attachment checkbox and tap **Save**.

Reply to a Text or Multimedia Message

1. Press  and tap  **Apps** >  **Messaging**.
2. From the message list, tap a message.
3. Tap the **Enter message** field and then type your reply message.
4. Once complete, tap  to send the message.

Protect a Message from Deletion

You can lock a message so that it will not be deleted even if you delete the other messages in the conversation.

1. Press  and tap  **Apps** >  **Messaging**.
2. On the Messaging screen, tap a message thread.
3. Touch and hold the message that you want to lock.

4. Tap **Lock** on the options menu. A lock icon displays at the lower right hand side of the message.

Delete a Message Thread

1. Press  and tap  **Apps** >  **Messaging**.
2. Touch and hold the message thread that you want to delete.
3. Tap **Delete thread**.

Delete Several Message Threads

1. Press  and tap  **Apps** >  **Messaging**.
2. Tap  > **Delete**.
3. Select the message threads you want to delete and tap **Delete**.

Note: Any locked messages will not be deleted, unless you select the **Include protected messages** check box before confirming the deletion.

Delete a Single Message

1. Press  and tap  **Apps** >  **Messaging**.
2. While viewing a message thread, touch and hold the message that you want to delete.
3. Tap **Delete** on the options menu.
4. When prompted to confirm, tap **OK**.

View Contact Details and Communicate with a Contact

When you have received a message from someone in your stored contacts, you can tap the contact's photo or icon in the message thread to open a menu of options. Depending on the stored contact information, you can view the contact details, phone, or send an email message to the contact, and more.

Messaging Settings

Messaging settings allow you control options for your text and MMS messages, including message limits, size settings, and notifications.

1. Press  and tap  **Apps** >  **Messaging**.
2. Tap  > **Settings**, and then configure these options:

- **Delete old messages** allows the phone to automatically delete the oldest messages when the maximum number of messages is reached. Set the maximum number of messages with the Text message limit and Multimedia message limit settings below.
- **Text message limit** allows you to set the maximum number of text messages per conversation.
- **Multimedia message limit** allows you to set the maximum number of multimedia messages per conversation.
- **Text templates** allows you to create and manage text strings that you can add to messages.
- **Auto combination** allows you to choose whether long messages that are received in multiple parts are automatically re-assembled to display as a single message.
- **Group messaging** allows you to control how messages to multiple recipients are handled. When enabled, a single message is sent to multiple recipients. When disabled, a separate message is sent to each recipient.
- **Auto retrieve** allows you to choose whether message attachment(s) are automatically downloaded when you display a multimedia message. If you disable this option, only the message header displays in the message list, and you'll be prompted to download the attachment(s).
- **MMS alert** allows you to have the phone alert you when you make a change to a message that will convert the message to a multimedia message (MMS).
- **Bubble style** allows you to choose how messages appear on the screen. Bubbles are the boxes that surround each message.
- **Background style** allows you to choose the background of the message screen.
- **Use the volume key** allows you to change the text size while reading a message by pressing the Volume Key up or down.
- **Notifications** allows you specify whether notifications for new messages display in the status bar.
- **Select ringtone** allows you to set the ringtone for your message notifications.
- **Vibrate** allows you to choose whether vibration plays along with the ringtone for new message notifications.
- **Message alert repetition** allows you to choose how often your phone notifies you of new message(s).
- **Preview message** allows you to choose whether a preview of a new message appears in the status bar with the message notification.

- **Emergency Alerts** allows you to configure emergency alert settings. You can enable or disable some alerts: Extreme Alert, Severe Alert, Amber Alert, and Emergency alert test messages. You cannot disable Presidential alerts.

Important: The Commercial Mobile Alert System (CMAS) system provides the government the ability to send geographically targeted notifications of emergencies, such as threats to public safety, severe weather events, a hazardous material spill or a missing child in the phone user's area.

- **Emergency notification preview** allows you to play a sample emergency alert tone. Tap **Stop** to cancel the playback.
- **Vibrate** allows you to select vibrate options for emergency messages.
- **Alert reminder** allows you to configure the reminder interval.
- **Add signature** allows you add a text signature to all messages you send.
- **Signature text** allows you to enter a text signature, when Add signature is enabled.
- **Spam settings** allows you to filter incoming messages for spam messages.
- **Add to spam numbers** allows you to enter telephone numbers, to automatically flag messages from the numbers as spam, when Spam settings is enabled.
- **Add to spam phrases** allows you to enter a text phrase, to automatically flag messages as spam when they contain the phrase. Available when Spam settings are enabled.
- **Block unknown senders** allows you to automatically block messages from numbers that are not stored as contacts on your phone

Social Networking Accounts

Stay in touch on the go with all your social networking accounts. Post updates on Facebook and Twitter, review your LinkedIn contacts, see what everyone's talking about from YouTube, and more.

Flipboard

The Flipboard application creates a personalized digital magazine out of everything being shared with you. Access news stories, personal feeds and other related material. Flip through your Facebook newsfeed, tweets from your Twitter account, photos from friends and much more.

- Press  and tap  **Apps >**  **Flipboard.**

Google+

Google+ makes messaging and sharing with your friends a lot easier. You can set up Circles of friends, visit the Stream to get updates from your Circles, use Messenger for fast messaging with everyone in your Circles, or use Instant Upload to automatically upload videos and photos to your own private album on Google+. Visit google.com/mobile/+/ for more information.

Google+ uses your Google account. If you don't already have a Google account set up on your phone, you can set one up.

1. Press  and tap  **Apps** >  **Google+.**
2. If you are signed into more than one Google account, select the account you would like to use with Google+.
3. Follow the onscreen instructions to use Google+.

Hangouts

Hangouts is an application for instant messaging offered by Google. Conversation logs are automatically saved to a Chats area in your Gmail account. This allows you to search a chat log and store them in your Gmail accounts.

Note: Hangouts is part of the Google group of apps.

1. Press  and tap  **Apps** >  **Hangouts.**
2. Tap **ADD ACCOUNT** to add a Google account to Google Hangouts. Tap **New** to create a new Google account, or tap **Existing** to sign in to an existing Google account.
3. After entering your user name and password, tap **Sign in.**
4. Follow the prompts to begin using Google Hangouts.

Note: If you have already signed into your Google account, it displays on the Hangouts screen.

YouTube

YouTube™ is a video sharing website on which users can upload and share videos. The site is used to display a wide variety of user-generated video content, including movie clips, TV clips, and music videos, as well as video content such as video blogging, informational shorts, and other original videos.

YouTube is a data-intensive feature. Check your data plan to avoid additional data charges.

- Press  and tap  **Apps** >  **YouTube.**

Apps and Entertainment

All your phone's features are accessible through the Apps list.

Samsung Link

Samsung Link makes staying connected easy. You can wirelessly synchronize your Samsung device with your TV, stream content, and even keep tabs on who calls or sends text messages with real-time, on-screen monitoring.

Samsung Link allows users to share their in-device media content with other external devices using DLNA certified™ (Digital Living Network Alliance) Devices. These external devices must also be DLNA-compliant. Wi-Fi capability can be provided to TVs via a digital multimedia streamer (not included).

Samsung Link uses your Samsung account. The first time you launch Samsung Link, follow the prompts to sign in to your Samsung account, or create a new account.

Both your phone, and the devices that connect to your phone, must be on the same Wi-Fi access point (AP). For more information about using Wi-Fi, see [Wi-Fi](#).

Note: Depending on the software version on your phone, you may see AllShare Play preloaded, or Samsung Link. If you have AllShare Play, you'll be prompted to upgrade to Samsung Link the first time you launch AllShare Play.

1. Press  and tap  **Apps** >  **Samsung Link**.
2. Follow the prompts to sign in to your Samsung account and learn about Samsung Link.
3. On the Samsung Link screen, swipe your finger left or right across the screen to scroll between Photos, Music, Video, or Document types.
4. To set options for Samsung Link, swipe right from the edge of the screen for options:
 - **All content:** Display all content categories.
 - **Registered devices:** Stream or share multimedia content from your device to other DLNA-compliant devices connected to the same Wi-Fi network. When you launch Samsung Link, compatible devices on the same Wi-Fi network display automatically in Registered devices.
 - **Registered storage:** Add storage service(s) to view multimedia files anywhere. Storage services include Web storage, such as DropBox or other services. Web storage is sometimes referred to as the "cloud."

Configure Samsung Link Settings

Configure Samsung Link options, such as storage location, account information, and registered storage services.

1. Press  and tap  **Apps** >  **Samsung Link**.
2. Tap  > **Settings** for options:
 - **Registered storage:** Add a Web storage service, to view or share files.
 - **Save to:** Choose a default file storage location. You can save to your phone's internal memory or to an optional installed memory card (SD card, not included).
 - **Auto upload:** When turned On, photos and videos from your device will be automatically uploaded to your PC, or to a Web storage service. You can also choose how files are uploaded. Turn On **Use mobile networks** to allow your phone to use your phone's connection to the wireless data network, or turn it Off to only allow uploads when connected to Wi-Fi.
 - **Video optimization:** When turned On, video quality for streamed video content is optimized depending on current network conditions.
 - **Password lock:** When turned On, access to Samsung Link on your device is password-protected. You must enter your Samsung account password to start Samsung Link.
 - **My account:** Access information about your Samsung account.
 - **About this service:** Learn about Samsung Link.

Use Samsung Link to Share Media with Another Device

Share media with another DLNA-compliant device via Samsung Link.

Both your device, and the device(s) that connect to your device, must be on the same Wi-Fi access point (AP). For more information about using Wi-Fi, see [Wi-Fi](#).

1. Press  and tap  **Apps** >  **Samsung Link**.
2. Launch AllShare Play or Samsung Link on the target device.
3. On the DEVICES & STORAGE screen, tap your device, and then tap media file(s) to select them for streaming.
4. Tap , and then choose a device for sharing. Your device requests permission for sharing from the target device.

Follow the prompts on the target device to allow sharing.

Group Play

Use Group Play to share media from your phone to other devices, via Wi-Fi, using your phone as an AP (Access Point).

Many of your phone's apps offer sharing via Group Play. Tap  to find sharing options, usually from the **Share via** list of options.

To use Group Play, all participants must be connected to the same Wi-Fi network.

Important: If you are using Group Play via an unsecured Wi-Fi network, your information may be vulnerable to unauthorized third parties while being transferred.

Use Group Play only for personal and non-profit purposes. Using Group Play for commercial use violates copyright law. The company is not responsible for copyright infringement by users.

Create a Group and Share

Note: To use Group Play, all participants must be connected to the same Wi-Fi network.

1. Press  and tap  **Apps** >  **Group Play**.
2. Tap **Set group password** > **Create Group**, and then follow the prompts to create a group. Participants will use the password to join your Group Play session.
3. After you create the group, your phone turns on the mobile AP (Access Point). Follow the onscreen directions to bring other devices back-to-back with your phone to join the group.
4. Choose options for sharing:
 - **Share music:** Select music stored on your phone or on an optional installed memory card (not included).
 - **Share images:** Select pictures stored on your phone or on an optional installed memory card (not included).
 - **Share documents:** Select documents stored on your phone or on an optional installed memory card (not included).
 - **Play games and more:** Play games with other participants and explore other types of content to share.

Note: For more information about using Group Play, tap  > **Info**.

Join a Group

1. Press  and tap  **Apps** >  **Group Play**.
2. Tap **Join Group**. Your phone scans for nearby available groups. Your device can only detect groups on the same Wi-Fi network your phone is connected to.
3. Select a group to join. After connecting, you can see and interact with the group's shared media.

DivX

DivX is a digital media format that provides your phone with high-quality videos.

DivX Legal Information

DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.

DivX Certified® to play DivX® video up to HD 720p, including premium content.

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that has passed rigorous testing to verify that it plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu (tap **Apps** > **Settings** > **More** > **About device** > **Legal information** > **License settings** > **DivX® VOD** > **Register**). Go to vod.divx.com for more information on how to complete your registration.

Important: DivX VOD content is protected by a DivX DRM (Digital Rights Management) system that restricts playback to registered DivX Certified devices.

Locating Your VOD Registration Number

Follow these procedures to locate your VOD registration number.

- Press  and tap  > **Settings** > **More** > **About device** > **Legal information** > **License settings** > **DivX® VOD** > **Register**.

Register Your DivX Device for VOD Playback of Purchased Movies

To play purchased DivX movies on your phone, you will first need to complete a one-time registration using both your phone and your computer.

1. Locate your VOD Registration code. Press  and tap  > **Settings > More > About device > Legal information > License settings > DivX® VOD > Register.**
2. Open the DivX Player on your computer. To download the free player for your computer, visit divx.com.
3. From the DivX Player on your computer, choose the VOD menu and select Register a DivX Certified Device...Follow the prompts to log in, or create a DivX account if you don't already have one.
4. Follow the instructions in DivX Player to enter your phone's VOD registration code and create a phone nickname.
5. Choose a location on your computer to download the DivX registration video, and then download the file.
6. Connect your phone to the computer via USB and transfer the DivX registration video to your phone. From the Registration screen (Transfer), select USB (the phone) as the target destination for the DivX registration video and tap Start. Return to the DivX VOD Manager screen (in your computer's DivX Player) and confirm both your computer and your new phone appears in the list of registered DivX devices.

Note: There is no special registration or configuration necessary to play back DRM-free DivX movies. Registration of your phone is only required for playback of DivX material.

Google Play Store

The Google Play Store is the place to go to find new Android apps, games, movies, music, and books for your phone. Choose from a wide variety of free and paid apps ranging from productivity apps to games. When you find an app you want, you can easily download and install it on your phone.

To access the Google Play Store you must have a Google Account set up on your phone. See [Sign In to Your Google Account](#) for details.

Important: Third-party applications may access your personal information or require your service provider to disclose your customer information to the third-party application provider. To find out how a third-party application will collect, access, use, or disclose your personal information, check the application provider's policies, which can usually be found on their website. If you aren't comfortable with the third-party application's policies, don't use the application.

Find and Install an App

When you install apps from the Google Play Store app and use them on your phone, they may require access to your personal information (such as your location, contact data, and more) or access to certain functions or settings of your phone. Download and install only apps that you trust.

Note: You need a Google Wallet account to purchase items from the Google Play Store app.

1. Press  and tap  **Apps** >  **Play Store**.
2. Browse through the categories (**Apps**, **Games**, **Music**, **Books**, or **Movies**), find an app you're interested in, and tap the name.
3. Follow the prompts to download and install the app.

Warning: Read the notification carefully! Be especially cautious with apps that have access to many functions or a significant amount of your data. Once you tap **OK** on this screen, you are responsible for the results of using this item on your phone.

Create a Google Wallet Account

You must have a Google Wallet account associated with your Google Account to purchase items from the Google Play Store app.

Do one of the following:

- On your computer, go to google.com/wallet/.

- or -

The first time you use your phone to buy an item from the Google Play Store app, follow the prompts to enter your billing information and set up a Google Wallet account.

Warning: When you've used Google Wallet once to purchase an item from the Google Play Store app, the phone remembers your information, so you don't need to enter it the next time. For this reason, you should secure your phone to prevent others from using it without your permission. (For more information, see [Security Settings](#).)

Open an Installed App

There are several options for opening an installed app.

- Press  and tap  **Apps** and tap the app icon.

Uninstall an App

You can uninstall any app that you have downloaded and installed from Google Play. You cannot uninstall apps that are preloaded on your phone.

1. Press  and tap  > **Settings** > **More** > **Application manager** > **Downloaded**.
2. Tap the app you want to uninstall, and then tap **Uninstall**.
3. Follow the prompts to complete the uninstall.

Google Play Books

With Google Play Books, you can find more than 3 million free e-books and hundreds of thousands more to buy in the Google Play Store.

- Press  and tap  **Apps** >  **Play Books**.

Google Play Magazines

With Google Play Magazines, you can subscribe to your favorite magazines and have them available to read on your phone at any time or any place.

- Press  and tap  **Apps** >  **Play Magazines**.

Google Play Movies & TV

The Google Play Movies & TV application allows you to connect to the Google Play Store and download a movie or TV show to watch instantly. Choose from thousands of movies and TV shows, including new releases and HD titles in Google Play and stream them instantly on your Android phone. Previously rented movies are automatically added to your My Movies library across your phones. Learn more about Google Play Movies at: play.google.com/about/movies.

1. Press  and tap  **Apps** >  **Play Movies & TV**.
2. Log in to your Google account if you have not already done so, and then follow the onscreen instructions for renting and viewing movies.

Google Play Music

Google Play Music lets you browse, shop, and play back songs purchased from the Google Play Store app, as well as songs you have loaded from your own music library. The music you choose is automatically stored in your Google Music library and instantly ready to play or download.

- Press  and tap  **Apps** >  **Play Music**.

Music App

The Music app plays music files. Launching Music allows you to navigate through your music library, play songs, and create playlists.

1. Press  and tap  **Apps** >  **Music**.
2. Tap a library category at the top of the screen (**Songs**, **Playlists**, **Albums**, **Artists**, or **Folders**) to view the available music files.

3. Scroll through the list of songs and tap an entry to begin playback.

Google Maps

Use the Google Maps application to find directions, location information, business addresses, etc. Determine your current location with or without GPS, get driving and transit directions and get phone numbers and addresses for local businesses.

Google Maps may require you to turn on Location services. For more information about location services, see [Location Services](#).

- Press  and tap  **Apps** >  **Maps**.

Web and Data

The following topics address your phone's data connections and the built-in Web browser. Additional data-related features can be found in [Accounts and Messaging](#), [Apps and Entertainment](#), and [Tools and Calendar](#).

Your phone's data capabilities let you wirelessly access the Internet or your corporate network through a variety of connections, including:

Internet

Your phone's Web browser gives you full access to both mobile and traditional websites on the go, using your phone's 3G, 4G, or Wi-Fi data connections.

- Press  and tap  **Apps** >  **Internet**.

Note: The first time you access the Web on your phone, you may be prompted to sign in with your phone number. Enter your number and tap **Ok**.

Chrome

Use Chrome for Mobile to browse fast and sign in to bring your Chrome experience from your computer, anywhere you go.

For more information, visit: <https://www.google.com/intl/en/chrome/browser/mobile/>

- Press  and tap  **Apps** >  **Chrome**.

Data Services (3G and 4G)

With your phone and its wireless features, you are ready to start enjoying the advantages of data services. The following topics will help you learn the basics of using data services, including managing your user name, launching a data connection, and navigating the Web with your phone.

Important: Certain data services requests may require additional time to process. While your phone is loading the requested service, the touchscreen keyboard may appear unresponsive when in fact it is functioning properly. Allow the phone some time to process your data usage request.

Your Data Services User Name

When you buy your phone and sign up for service, you're automatically assigned a user name, which is typically based on your name and a number.

Find Your User Name

1. Press  and tap  > **Settings** > **More** > **About device**.
2. Tap **Status**, and then find your user name under the User name heading.

4G Services

Your phone supports 4G LTE. 4G is a service that must be included in your service plan and also available in your area. 4G coverage is currently available in only certain markets.

Note: If 4G service is not available in your location, the 4G icon will not appear in the Notifications area.

Not all services are available on 4G and coverage may default to 3G/separate network where 4G unavailable.

Depending on which icons appear in the Notifications area, your services and features will change. The following table indicates what functions and features are available when combinations of these service icons appear:

Icon	Description
3G	3G Coverage: The phone is connected to a 3G network. When data is being transferred, the arrows are colored.
4GLTE	4G Coverage: The phone is connected to a 4G network. When data is being transferred, the arrows are colored.

Wi-Fi

Wi-Fi provides wireless Internet access over distances of up to 300 feet. To use your phone's Wi-Fi, you need access to a wireless access point or "hotspot."

The availability and range of the Wi-Fi signal depends on a number of factors, including infrastructure and other objects through which the signal passes.

Turn Wi-Fi On and Connect to a Wireless Network

By default, your phone's Wi-Fi feature is turned off. Turning Wi-Fi on makes your phone able to discover and connect to compatible in-range Wi-Fi networks (or WAPs - wireless access points).

Turn Wi-Fi On

- Press  and tap  > **Settings** > **Connections** > **Wi-Fi**. The On/Off slider displays ON when Wi-Fi is active.

Tip: You can also turn Wi-Fi on and off through the Notifications panel. Drag the Notifications panel down and tap **Wi-Fi** to enable or disable Wi-Fi.

Note: Wi-Fi networks are self-discoverable, which means no additional steps are required for your phone to connect to a Wi-Fi network. It may be necessary to provide a user name and password for certain closed wireless networks.

Connect to a Wi-Fi Network

1. Press  and tap  > **Settings** > **Connections** > **Wi-Fi**.
2. The network names and security settings (Open network or Secured with xxx) of detected Wi-Fi networks are displayed.
 - When you select an open network, you will be automatically connected to the network.
 - When you select a secured network, you will need to enter the wireless password to connect to the network. Enter the password and tap **Connect**. You can use the **show password** option to display the password as you enter it.

Manually Add a New Network Connection

1. Press  and tap  > **Settings** > **Connections** > **Wi-Fi**.
2. Tap **Add Wi-Fi network**.
3. Enter the Network SSID. This is the name of your Wi-Fi network.
4. Tap the **Security** field and select a security option. This must match the current security setting on your target network.
5. Tap **Connect** to store the new information and connect to the Wi-Fi network.

Note: The next time your phone connects to a previously accessed or secured wireless network, you are not prompted to enter the wireless password again, unless you reset your phone back to its factory default settings.

Scan for a Wi-Fi Network

1. Press  and tap  > **Settings** > **Connections** > **Wi-Fi**.
2. Tap **Scan**.

Bluetooth

Bluetooth is a short-range communications technology that allows you to connect wirelessly to a number of Bluetooth phones, such as headsets and hands-free car kits, and Bluetooth-enabled

handhelds, computers, printers, and wireless phones. The Bluetooth communication range is usually approximately 30 feet.

Turn Bluetooth On or Off

The following procedures will guide you through turning on and turning off your Bluetooth phone.

1. Press  and tap  > **Settings** > **Connections** > **Bluetooth**.
2. Tap the **ON/OFF** slider to move it into the **ON** position to turn Bluetooth on.

Tip: You can also turn Bluetooth on and off through the Notifications panel. Drag the Notifications panel down and tap **Bluetooth** to enable or disable Bluetooth.

Note: Turn off Bluetooth when not in use to conserve battery power, or in places where using a wireless phone is prohibited, such as aboard an aircraft and in hospitals.

Connect a Bluetooth Headset or Car Kit

You can listen to music over a Bluetooth stereo headset, or have hands-free conversations using a compatible Bluetooth headset or car kit. It's the same procedure to set up stereo audio and hands-free devices.

To listen to music with your headset or car kit, the headset or car kit must support the A2DP Bluetooth profile.

1. Press  and tap  > **Settings** > **Connections** > **Bluetooth**.
2. If Bluetooth is not on, tap the on-off slider to turn it on.
3. Make sure that the headset is discoverable, so that your phone can find the headset. Refer to the instructions that came with the headset to find out how to set it to discoverable mode.
4. Tap **Scan**. Your phone will start to scan for Bluetooth devices within range.
5. When you see the name of your headset displayed in the Bluetooth devices section, tap the name. Your phone then automatically tries to pair with the headset.
6. If automatic pairing fails, enter the passcode supplied with your headset.

The pairing and connection status is displayed below the hands-free headset or car kit name in the Bluetooth devices section. When the Bluetooth headset or car kit is connected to your

phone,  (Bluetooth connected) displays in the status bar. Depending on the type of headset or car kit you have connected, you can then start using the headset or car kit to listen to music or make and receive phone calls.

Note: Due to different specifications and features of other Bluetooth-compatible devices, display and operations may be different, and functions such as transfer or exchange may not be possible with all Bluetooth-compatible devices.

Reconnect a Headset or Car Kit

When you have paired a headset with your phone, you should be able to reconnect it automatically by turning on Bluetooth on your phone and then turning on the headset. However, sometimes you will need to reconnect manually, for example if you have been using your headset with another Bluetooth device.

1. Press  and tap  > **Settings** > **Connections** > **Bluetooth**.
2. If Bluetooth is not on, tap the on-off slider to turn it on.
3. Make sure that the headset is discoverable.
4. Tap the headset's name in the Bluetooth devices section.
5. If prompted to enter a passcode, try 0000 or 1234, or consult the headset or car kit documentation to find the passcode.
6. If you still cannot reconnect to the headset or car kit, follow the instructions in [Disconnect or Unpair From a Bluetooth Device](#), and then follow the instructions in [Connect a Bluetooth Headset or Car Kit](#).

Disconnect or Unpair from a Bluetooth Device

Follow these instructions to disconnect or unpair your phone from a Bluetooth device.

Disconnect from a Bluetooth Device

1. Press  and tap  > **Settings** > **Connections** > **Bluetooth**.
2. In the Bluetooth devices section, tap the device, and then follow the prompts to confirm the disconnection.

Unpair from a Bluetooth Device

You can make your phone forget its pairing connection with another Bluetooth device. To connect to the other device again, you may need to enter or confirm a passcode again.

1. Press  and tap  > **Settings** > **Connections** > **Bluetooth**.
2. In the Bluetooth devices section, tap  next to the device, and then select **Unpair**.

Send Information Using Bluetooth

You can use Bluetooth to transfer information between your phone and another Bluetooth-enabled device such as a phone or notebook computer. The first time you transfer information

between your phone and another device, you need to enter or confirm a security passcode. After that, your phone and the other device are paired, and you will not need to exchange passcodes to transfer information in the future.

You can send the following types of information, depending on the device you are sending to:

- Images and videos
- Calendar events
- Contacts
- Audio files

The location where the information is saved depends on the type of information and the receiving device.

Send Information from Your Phone to Another Device

1. Set the receiving device to discoverable mode. You may also need to set it to “Receive Beams” or “Receive Files”. Refer to the device’s documentation for instructions on receiving information over Bluetooth.
2. On the phone, open the application that contains the information or file you want to send.
For example, if you want to send a photo, press  and tap  >  **Gallery**.
3. Follow the steps for the type of item you want to send:
 - **Photo or video** (in Camera). After capturing a photo, on the preview screen, tap  > **Bluetooth**.
 - **Photos and videos** (in Gallery). On the **Albums** tab, tap an album, tap an item, and then tap  > **Bluetooth**.
 - **Calendar event**: In the Calendar’s Day view, Agenda view, or Week view, tap the event and then tap  > **Share via** > **Bluetooth**.
 - **Music track**: This feature is available through the **Music** app. With the track displayed on the Now playing screen, tap  > **Share via** > **Bluetooth**.
 - **Voice recording**: On the main Voice Recorder screen, touch and hold a recording and then tap **Share via** > **Bluetooth**.
4. If you are prompted to turn on Bluetooth, tap **OK**.
5. Tap the name of the receiving device.

6. If prompted, accept the connection on the receiving phone, and enter the same passcode on both your phone and the other device, or confirm the auto-generated passcode.
7. On the receiving device, accept the file.

Receive Information Using Bluetooth

Your phone is capable of receiving a wide variety of file types with Bluetooth, including photos, music tracks, and documents such as PDFs.

1. Press  and tap  > **Settings** > **Connections** > **Bluetooth**.
2. If Bluetooth is not on, tap the on-off slider to turn it on.
3. Tap the check box next to your phone's Bluetooth name to make it discoverable.
4. On the sending device, send one or more files to your phone. Refer to the device's documentation for instructions on sending information over Bluetooth.
5. If prompted, enter the same passcode on both your phone and the other device, or confirm the auto-generated passcode. A Bluetooth authorization request is displayed on your phone.
6. If you want to automatically receive files from the sending device in future, select the **Always allow this device** check box.

When a file is transferred, a notification is displayed. Tap **Accept**. To open the file immediately, slide down the notifications panel, and then tap the relevant notification.

When you open a received file, what happens next depends on the file type.

Virtual Private Networks (VPN)

From your phone, you can add, set up, and manage virtual private networks (VPNs) that allow you to connect and access resources inside a secured local network, such as your corporate network.

Prepare Your Phone for VPN Connection

Depending on the type of VPN, you may be required to enter your login credentials or install security certificates before you can connect to your company's local network. You can get this information from your network administrator.

To connect to a VPN, you must have Mobile data enabled, or your phone must be connected to a Wi-Fi network. For information about setting up and using these connections on your phone, see [Mobile networks](#) and [Turn Wi-Fi On and Connect to a Wireless Network](#).

Set a Screen Lock

Before setting up a VPN, you must set a screen lock to prevent access to your phone by unauthorized users. Pattern, PIN, or password screen locks provide sufficient security to set up trusted credential storage.

1. Press  and tap  > **Settings** > **My device**.
2. Tap **Lock screen** > **Screen lock**.
3. Choose a screen lock, from Pattern, PIN, or Password.
4. Follow the prompts to configure the screen lock. For more information, see [Screen lock](#).

Add a VPN

The following procedures outline the method to use when adding a VPN connection.

1. Press  and tap  > **Settings** > **Connections**.
2. Tap **More networks** > **VPN**.
3. Tap , and then enter the information for the VPN you want to add. The information you may need to enter includes **Name**, **Type**, **Server address**, and other information for your VPN network. Consult your network administrator for more details.
4. When finished, tap **Save**.

Connect to a VPN

The following describes how to connect to a VPN.

1. Press  and tap  > **Settings** > **Connections**.
2. Tap **More networks** > **VPN**.
3. In the VPNs section, tap a VPN.
4. Follow the prompts to enter your login credentials and connect. When you are connected, the VPN connected icon appears in the Status bar.

Pictures and Video

Camera


Use the camera to take and share pictures and videos.

Important: Do not take photos of people without their permission. Do not take photos in places where cameras are not allowed. Do not take photos in places where you may interfere with another person's privacy.

Take Pictures

Launch the Camera app to take pictures.

1. Press  and tap  **Apps** >  **Camera**.



2. Using the display as a viewfinder, compose your picture by aiming the lens at the subject. You can rotate the phone to any position, and the screen controls rotate to make taking pictures easy.
3. As you compose a picture, the Camera automatically focuses the shot (the focus bracket turns green), or:
 - Touch the screen to focus on the area you touched.
 - “Pinch” the screen, or press the **Volume Key**, to zoom in or out.
 - Configure other options. For more information, see [Picture Options](#).
4. To take the picture, tap **Capture**.

Picture Options

Set options for the pictures you take.

1. Press  and tap  **Apps** >  **Camera**.
2. Configure these options:
 - **Self-portrait:** Switch between the back camera and the front camera, for self-portraits.
 - **Flash:** Choose a flash setting.
 - **Shooting mode:** Choose an automatic shooting mode. Some modes are not available for Self-portraits.
 - **Single shot:** Take a single photo.
 - **Best photo:** Hold down Capture to take multiple shots; then choose the best shots to keep.
 - **Best face:** Hold down Capture to take multiple shots; then choose the best “face” on a photo subject to use that face in the final shot.
 - **Sound & shot:** Record up to 9 seconds of sound with each picture you take. You can record sound when you take the picture, or after the picture is taken.
 - **Face detection:** While composing a picture, double-tap on a face to zoom in or out.
 - **Panorama:** Touch Capture to take a picture; then use the onscreen guideline to move the viewfinder and take the next 7 shots automatically.
 - **Share shot:** Share the pictures you take, with other Share Shot-capable devices via Wi-Fi Direct.
 - **HDR:** Take photos in High Dynamic Range (HDR) mode to increase detail.
 - **Buddy photo share:** When you take a picture, the Camera recognizes faces from Contacts, so you can easily share the picture with your friends.
 - **Beauty:** Adjust the contrast to create a smooth facial feature effect.
 - **Smile shot:** Touch Capture to focus on the subject’s face. If a smile is detected, the picture is taken automatically.
 - **Low light:** Adjust exposure automatically, for optimum picture-taking in low-light conditions. Be careful not to shake the phone while taking pictures.
 - **Effects:** Apply an effect to pictures.
 - **Options**

- **Edit shortcuts:** Choose shortcuts to appear on the toolbar. Touch and drag shortcuts between the toolbar and the list.
- **Burst shot:** When On, touch and hold the Capture button to take up to 20 shots automatically.
- **GPS Tag:** Add GPS location information to photo details.
- **Self-portrait:** When On, the Camera takes pictures with the front Camera.
- **Flash:** Choose the default flash mode.
- **Shooting mode:** Choose the default mode for taking pictures.
- **Effects:** Apply an effect to pictures.
- **Scene mode:** Choose a mode to match the kind of pictures you're taking.
- **Exposure value:** Set the default brightness level.
- **Focus mode:** Set the default focus mode.
- **Timer:** Set a delay to wait between touching the Camera button and taking a picture.
- **Resolution:** Choose a size for the image.
- **White balance:** Choose a setting for the light source.
- **ISO:** Choose a setting for imaging sensitivity.
- **Metering:** Select a method for measuring light.
- **Auto contrast:** Allow automatic light/dark adjustment.
- **Guidelines:** Enable or disable an on-screen grid to aid in photo composition.
- **Auto share shot:** When turned On, you can easily connect to other devices via S Beam to share pictures with other S Beam devices. To share pictures, bring the devices back-to-back. For more information, see [S Beam](#).
- **Anti-shake:** When enabled, minimizes the effect of camera movement.
- **Contextual filename:** When enabled, the filename the camera to the picture includes GPS information.
- **Voice control:** When enabled, you can speak a command to capture a picture.
- **Image quality:** Choose a quality setting for photos.

- **Storage:** If an optional memory card is installed (not included), choose the default storage location for pictures. By default all pictures are stored to the phone's internal memory.
- **Reset:** Set all Camera settings to the defaults.

Record Videos

Use the Camera to record video.

Important: Do not take videos of people without their permission. Do not take videos in places where cameras are not allowed. Do not take videos in places where you may interfere with another person's privacy.

1. Press  and tap  **Apps** >  **Camera**, and then tap **Mode** to switch to recording mode.



2. Choose a recording mode. You can choose to limit the size of the video so that it can be sent in a message, or continue with normal recording.
3. Using the display as a viewfinder, compose your shot by aiming the lens at the subject. You can rotate the phone to any position, and the screen controls rotate to make recording easy.
4. As you compose a shot, the Camera automatically focuses the shot (the focus bracket turns green), or you can:
 - “Pinch” the screen to zoom in or out.
 - Configure options.
5. Tap  **Record** to begin recording. While recording, you can use these options:
 - Tap the screen to change the focus area to the area you tapped.

- Tap  **Capture** to take a still picture while continuing recording.
- Tap  **Pause** to temporarily stop recording.
- Tap  **Stop** to stop recording.

Video Options

Configure options for videos.

1. Press  and tap  **Apps** >  **Camera**, and then tap **Mode** to switch to recording mode.
2. Configure these options:
 - **Self-recording:** Switch between the back camera and the front camera, for recording yourself.
 - **Flash:** Choose a flash setting.
 - **Recording mode:** Choose an automatic shooting mode. Some modes are not available for Self-portraits.
 - **Normal:** Record a video of any length (limited only by memory space).
 - **Limit for MMS:** Restrict the length of the video so it can be sent as a message attachment.
 - **Effects:** Apply an effect to pictures.
 - **Options**
 - **Edit shortcuts:** Choose shortcuts to appear on the toolbar. Touch and drag shortcuts between the toolbar and the list.
 - **GPS Tag:** Add GPS location information to photo details.
 - **Self-recording:** When On, the Camera records with the front Camera.
 - **Flash:** Choose the default flash mode.
 - **Recording mode:** Choose the default recording mode.
 - **Effects:** Apply an effect to videos.
 - **Exposure value:** Set the default brightness level.

- **Timer:** Set a delay to wait between touching the Camera button and starting recording.
- **Resolution:** Choose a size for the video.
- **White balance:** Choose a setting for the light source.
- **Guidelines:** Enable or disable an on-screen grid to aid in video composition.
- **Anti-Shake:** When enabled, minimizes the effect of camera movement.
- **Contextual filename:** When enabled, the camera assigns a filename to the video file, that includes GPS information.
- **Video quality:** Choose a quality setting for videos.
- **Storage:** If an optional memory card is installed (not included), choose the default storage location for videos. By default all videos are stored in the phone's internal memory.
- **Reset:** Set all Camera settings to the defaults.

Gallery

Using the Gallery application, you can view pictures and watch videos that you've taken with your phone's camera, downloaded, or copied to an optional memory card (not included).

For pictures stored on an optional memory card, you can do basic editing such as rotating and cropping. You can also set a picture as your contact picture or wallpaper and share pictures with your friends.

While viewing pictures in the Gallery, scroll up the screen to view more albums. Simply tap an album to view the photos or videos in that album.

If you have pictures or videos stored on an optional memory card (not included), they will be display folders they are stored in, and folders are treated as albums. The actual folder names will be used as the album names. If you have downloaded any photos and videos, these will be placed in the **All downloads** album.

1. Press  and tap  **Apps** >  **Gallery**.
2. Select a folder location (such as Camera) and tap an image to view your picture.
3. From the Gallery screen, you can use these options:
 - Tap a picture or video to display it in full screen view.
 - Touch and hold thumbnails to select them (indicated by a check mark).

- Tap  **Create album** to create an album. Give the album a name, and then select and drag thumbnails to the album to move or copy files to the new album.
- Tap  **Camera** to launch the Camera, to take pictures or record video.
- Tap  for options, including:
 - **Select album/Select item:** Depending on the view, tap albums or items to select them. After selection, you can tap  again for options you can use with the selected item.
 - **Slideshow:** Choose options to create a slideshow for viewing your pictures and videos.
 - **Content to display:** Choose content to display in Gallery. You can choose content saved to your phone's memory, content from other sources such as Dropbox, Facebook, or your Picasa™ account.
 - **Scan for nearby devices:** Search for nearby DLNA-compatible devices, to share media.
 - **Hide items/Show hidden items:** Use Hide items to choose items to hide from display. The items are not deleted, and can be displayed with the Show hidden items option.
 - **Settings:** Configure Gallery settings.

Note: Available options depend on which gallery screen you are viewing. Additional options may include Content to display, Scan for nearby devices, Show nearby devices, and Help

View Photos and Videos

After selecting an album from the Albums tab, you can browse the photos and videos of that album in either photo pile or grid view. Tap a photo or video to view it in full screen.

View Photos

1. Press  and tap  **Apps** >  **Gallery**.
2. Tap a thumbnail to view the picture. While viewing a picture full-screen you can use these options:
 -  **Screen mirroring:** Choose a device to share the picture via AllShare or Group Play.

-  **Share:** Choose an option for sharing the picture. Options may include Group Play, Dropbox, Bluetooth, Email, Flipboard, Gmail, Google+, Hangouts, Messaging, Picasa, S Memo, or Wi-Fi Direct.
-  **Delete:** Erase the current picture.
-  **Camera:** Launch the Camera, to take pictures or record video.

View Videos

Note: If no control icons are displayed on the screen in addition to the picture, tap anywhere on the screen to display them.

1. Press  and tap  **Apps** >  **Gallery**.
2. Tap a video to select it. When the video is displayed full-screen, you can use these options:
 -  **Share:** Choose an option for sharing the video. Options may include Bluetooth, Dropbox, Email, Gmail, Google+, Messaging, Picasa, Wi-Fi Direct, or YouTube.
 -  **Trim:** Edit the length of the video.
 -  **Delete:** Erase the current video.
 - Tap  to play the video.

Zoom In or Out on a Photo

There are two ways you can zoom in or out of a photo.

- Tap the screen twice quickly to zoom in and then tap the screen twice quickly again to zoom out.

- or -

You can also use pinch and spread to zoom in or out. See [Touchscreen Navigation](#).

Working with Photos

You can touch and hold on a photo to open a selection menu and choose what to do with it. You can choose to delete the photo, rotate or crop it, and more.

Rotate and Save a Photo

To rotate and save your photo, follow the below procedures.

1. Press  and tap  **Apps** >  **Gallery**.
2. Select a folder location (such as Camera) and tap an image to view your picture.
3. Tap  > **Rotate left** or **Rotate right**.

The rotated picture is saved in your default storage location as a copy.

Crop a Photo

To crop your photos, follow the below procedures.

1. Press  and tap  **Apps** >  **Gallery**.
2. Select a folder location (such as Camera) and tap an image to view your picture.
3. Tap  > **Crop**.
4. To adjust the crop box size, touch and hold the edge of the box. When directional arrows appear, drag your finger inward to or outward to resize the crop box.
5. To move the crop box to the part of the photo that you want to crop, drag the crop box to the desired position.
6. Tap **Done** to apply the changes to the picture.

The cropped picture is saved along with the original copy in your default storage location.

Share Photos and Videos

The Gallery application lets you send photos and videos using email or multimedia messages. You can share photos on your social networks (such as Facebook, Picasa, and Twitter) and share videos on YouTube. You can also send them to another phone or your computer using Bluetooth.

Send Photos or Videos by Email

You can send several photos, videos, or both in an email message. They are added as file attachments in your email.

1. Press  and tap  **Apps** >  **Gallery**.
2. Tap the album that contains the photos or videos you want to share.
3. Tap the photos you want to send.

4. Touch the screen and then tap  > **Gmail** or **Email**.

5. Compose your message and then tap  or .

Note: If you selected **Email** and you have multiple email accounts, the default email account will be used.

Send a Photo or Video by Multimedia Message

Although you can send several photos or videos in a multimedia message, it may be better to send one at a time, especially if the files are large in size.

1. Press  and tap  **Apps** >  **Gallery**.
2. Tap the album that contains the photos or videos you want to send.
3. Tap the photo or video you want to send.
4. Touch the screen and then tap  > **Messaging**.
5. Compose your message and then tap .

Send Photos or Videos Using Bluetooth

You can select several photos, videos, or both and send them to someone's phone or your computer using Bluetooth.

1. Press  and tap  **Apps** >  **Gallery**.
2. Tap the album that contains the photos or videos you want to send.
3. Select the photos or videos you want to send.
4. Touch the screen and then tap  > **Bluetooth**. In the next few steps, you'll be asked to turn on Bluetooth on your phone and connect to the receiving Bluetooth phone so the files can be sent. For more information, see [Bluetooth](#).

Share Photos or Videos on Google+

1. Press  and tap  **Apps** >  **Gallery**.
2. Tap the album that contains the photos or videos you want to send.
3. Tap the photo or video you want to send.

4. Touch the screen and then tap  > **Google+**.

Share Photos on Picasa

You need to be signed in to a Google Account to upload pictures to the Picasa photo organizing service.

1. Press  and tap  **Apps** >  **Gallery**.
2. Tap the album that contains the photos or videos you want to share.
3. Select the photos you want to share.
4. Touch the screen and then tap  > **Picasa**.
5. Select the online album where you want to upload the pictures.
6. Tap **Upload**. You can view the photos online at picasaweb.google.com.

Share Videos on YouTube

You can share your videos by uploading them to YouTube. Before you do this, you must create a YouTube account and sign in to that account on your phone.

1. Press  and tap  **Apps** >  **Gallery**.
2. Tap the album that contains the videos you want to share.
3. Select the video you want to share.
4. Touch the screen and then tap  > **YouTube**.
5. Enter the prompted information, such as description and tags, and select a privacy option.
6. Tap **Upload**.

Video App

The Video app plays video files stored on your phone, or on an optional installed memory card (not included).

- Press  and tap  **Apps** >  **Video**.

Paper Artist

Paper Artist allows you to quickly add stylized effects to your photos or images.

- Press  and tap  **Apps >**  **Paper Artist.**

G+ Photos

Keep all your photos backed up and organized with Google+ Photos.

- Press  and tap  **Apps >**  **G+ Photos.**

Tools and Calendar

Learn how to use many of your phone's productivity-enhancing features.

Calculator

Your phone comes with a built-in calculator.

1. Press  and tap  **Apps** >  **Calculator**.
2. Enter numbers by tapping the onscreen keyboard. Touch and hold **C** to clear all numbers.

Calendar

Use Calendar to create and manage events, meetings, and appointments. Your Calendar helps organize your time and reminds you of important events. Depending on your synchronization settings, your phone's Calendar stays in sync with your Calendar on the Web, Exchange ActiveSync calendar, and Outlook calendar.

Add an Event to the Calendar

Add events to your Calendar to help you organize your time and remind you of important events.

Note: To synchronize calendar events among your Google and Corporate accounts, make sure they are being managed by your phone. See [Accounts and Messaging](#) for more information.

1. Press  and tap  **Apps** >  **Calendar**.
2. Double-tap a day on the calendar, and then tap the Calendar field to assign the new event to an account, or save it to the phone.
3. Tap **Tap to enter title** and enter a title for the event.
4. Tap **OK** to save the event now, or tap **Edit event details** to enter more information:
 - Select a **From/To** time for the event by tapping the corresponding fields, and adjusting the month, day, and year.
 - If the event lasts all day, leave the All day check box checked, or tap to uncheck the box and enter a time for the event.
 - Select a recurrence cycle for the event by tapping the **Repeat** field.
 - Select an alarm time by tapping the **Reminder** field.

- Enter a location for the event in the **Location** field or tap  to select the location on a map.
- Enter a description for the event in the **Description** field.
- Enter participants in the **Participants** field.
- Tap **Show me as** to choose how the event shows on your calendar to other event organizers.
- Tap **Privacy** to select who is allowed to see this event. **Private** allows only the participants to see the event. **Public** allows anyone with access to your calendar to see the event.
- Tap **Memos** to attach an **S Memo** file. For more information, see [S Memo](#).
- Tap **Images** to add an image from the Gallery or take a new picture.

5. Tap **Save** to save the new event.

View Events

The following procedure helps you view your calendar events.

1. Press  and tap  **Apps**  **Apps** >  **Calendar**.
2. To change the calendar view, tap the **Year**, **Month**, **Week**, **Day**, **List**, or **Task** tab.
3. Tap the day for which you would like to view events. (Your phone lists events in chronological order.)
4. To display an event's details, tap it from the current screen.

Erase Events

The following procedures show you how to erase your calendar events.

1. Press  and tap  **Apps**  **Apps** >  **Calendar**.
2. Open the calendar event details:
 - In **List**, **Day**, and **Week** views, tap the calendar event you want to delete.
 - In **Month** view, tap the date where the calendar event occurs, and then tap the calendar event.
 - In **Year** view, tap the month in which the event is located.
3. Tap  > **Delete**.

4. In the Delete confirmation box, tap **OK**.

- or -

If the calendar event is recurring, select **Only this event**, **This & future events**, or **All events**, and tap **OK**.

Clock

Use Clock to keep track of time. Clock offers these features:

- Alarm
- World Clock
- Stopwatch
- Timer
- Desk Clock

Create an Alarm

1. Press  and tap  **Apps** >  **Clock**.
2. Tap **Create alarm**, and then enter information for the alarm.
3. Tap **Save** to store the new alarm event.

Delete an Alarm

1. Press  and tap  **Apps** >  **Clock**.
2. Touch and hold an alarm, and then tap **Delete**.

Downloads

The Downloads application allows you to manage files you download to your phone.

- Press  and tap  **Apps** >  **Downloads**.

Note: Applications you download from Google Play™ Store are managed with the Play Store application, and do not display in Downloads.

Dropbox

Dropbox works to provide access to your desktop files directly from your phone. This app allows you to bring your files with you when you're on the go, edit files in your Dropbox from your

phone, upload photos and videos to Dropbox, and share your selected files freely with family and friends.

The app works in conjunction with a partner program placed on a target computer using an active Internet connection.

Dropbox creates a folder that automatically synchronizes its contents across all of your connected devices on your account. Update a file to your Dropbox on your computer, and it's automatically updated to the same folder on your other devices.

Download the Desktop Application

Follow the procedures below to download the desktop application.

1. Use your computer's browser to navigate to: <http://www.dropbox.com/>.
2. Follow the onscreen setup and installation instructions on your target computer containing the desired files.

Important: The computer application must be installed on the computer containing the desired files. This computer must have an active Internet connection.

Access Dropbox on your Phone

Access the Dropbox app and set up your Dropbox account.

1. Press  and tap  **Apps** >  **Dropbox**.
2. Tap **Start**, and then tap **Sign up for Dropbox**, or tap **Sign in**.
3. Follow the onscreen instructions to sign in to your account, or register for a new account.

Manually Upload a Picture to Dropbox

Follow the below procedures to manually upload pictures to the Dropbox app.

1. Press  and tap  **Apps** >  **Camera**.
2. After the image is taken, tap the Image Viewer box at the bottom right. This previews the current image.
3. Tap the image to reveal the image options at the top of the screen.
4. Tap  > **Dropbox**, select a folder location, and tap **Upload**.

Note: If your share folder is located on your computer, you will momentarily receive an onscreen popup notifying you that a new image was uploaded to your shared Dropbox folder.

Flipboard

Use Flipboard to create a personalized digital “magazine” out of everything being shared with you. Access news stories, personal feeds and other related material. Flip through your Facebook newsfeed, tweets from your Twitter account, photos from friends and much more.

- Press  and tap  **Apps** >  **Flipboard**.

Google Search

Use Google Search to search the Internet.

- Press  and tap  **Apps** >  **Google**.

Help

Help provides online information to help with your phone questions.

- Press  and tap  **Apps** >  **Help**.

My Files

My files allows you to manage your manage sounds, images, videos, Bluetooth files, Android files, and files stored on your phone, or on an optional installed memory card (not included). You can open a file if the associated app is already on your phone.

1. Press  and tap  **Apps** >  **My files**.
2. The following folders display:
 - **All files:** Tap to choose Device storage, or SD memory card, to show files stored in the phone’s internal memory, or on an optional installed memory card (not included).
 - **Images:** Pictures stored on your phone.
 - **Videos:** Videos stored on your phone.
 - **Music:** Songs stored on your phone.
 - **Documents:** Other files stored on your phone.

Note: Different folders may appear depending on how your phone is configured.

S Memo

The S Memo application allows you to create memos using the keyboard, your finger, or both. You can add images, voice recordings, and text all in one place.

Follow the steps below to explore the S Memo app.

1. Press  and tap  **Apps** >  **S Memo**.
2. From the S Memo screen, tap  to access the following options:
 - **Search:** Tap to search for a saved memo.
 - **Delete:** Touch one or all memos and then tap **Done**.
 - **Sort by:** Choose how to sort the list of memos.
 - **View by list/View by thumbnail:** Tap to view your existing memos in a list or thumbnail (default) view.
 - **Share via:** Send a memo via Group Play, Dropbox, Flipboard, Picasa, Paper Artist, Hangouts, Google+, Bluetooth, Wi-Fi Direct, Messaging, Gmail, or Email.
 - **Export:** Export a memo.
 - **Sync:** Synchronize memo(s) with Evernote or Google+.
 - **Create folder:** Create a folder to store memos.
 - **Move:** Move a memo to a folder.
 - **Copy:** Copy a memo to the clipboard.
 - **Lock/Unlock:** When locked, a memo cannot be deleted.
 - **Print:** Print memo(s) via Wi-Fi to a compatible Samsung printer (not included).
 - **Settings:**
 - **Auto Sync:** Sync your settings on your phone or save them to you Samsung account.
 - **Change PIN:** Set a PIN number to use to lock your memos.
 - **Screen timeout:** Tap to select the length of time that the screen will display when you are in the S Memo application. Choose from **15 seconds**, **30 seconds**, **1 minutes**, **2 minutes**, **5 minutes**, or **10 minutes**.
 - **Handwriting language update:** Tap to update the software that translates your handwriting into text.

- **Auto hide toolbar:** Tap to hide the toolbar when entering a memo.
- **Help:** Learn about S Memo.
- **Backup and restore:** Save or import memos from an optional installed memory card (not included), or import memos..

Create a New S Memo

Follow the steps below to create a new memo or expand or reply to an existing memo using the S Memo app.

1. Press  and tap  **Apps** >  **S Memo**.

2. Tap  to start a new memo in text mode.

- or -

Tap  to start a new memo in drawing mode.

3. Tap  to access the following options:

Note: Depending on whether you have saved the memo, are in keyboard mode, or in drawing mode, the options will appear differently. The following is a list of the options you may see.

- **Rename:** Change the current memo title.
- **Share via:** Send a memo via Group Play, Dropbox, Flipboard, Picasa, Paper Artist, Hangouts, Google+, Bluetooth, Wi-Fi Direct, Messaging, Gmail, or Email.
- **Handwriting-to-text:** Transcribe handwriting into text.
- **Export:** Save the memo to memory, as a graphic or PDF.
- **Save as:** Save the memo with a different name.
- **Add picture:** Add an image to the current memo. Choose Picture, Take picture, Clip Art, Clipboard, or Map.
- **Add tag:** Set tags to add in searches.
- **Add to Favorites:** Tag the current memo as a favorite.
- **Change background:** Set the background for your memo. Swipe the screen to the left or right to select a background and then tap **Done**.
- **Link to Calendar:** Link the memo to your Calendar.
- **Lock:** Lock the memo by using a PIN number.

- **Set as:** Set a memo as a contact icon, Home screen wallpaper, Lock screen wallpaper, or a widget.
- **Print:** Print memo(s) via Wi-Fi to a compatible Samsung printer (not included).

4. When you are finished creating your memo, tap **Save**.

S Suggest

The S Suggest application provides onscreen recommendations for apps that are specifically supported and made for use on your phone.

Note: Access to this feature requires that you already be logged in to your Samsung account application.

1. Press  and tap  **Apps** >  **S Suggest**.
2. Read the terms and conditions.
3. Place a check mark in the Agree field then tap **Agree**.
4. Select an application from one of the available categories (Picks, Categories, Games, Friends, and Info).
5. Follow the onscreen download and installation instructions.

S Voice

Your phone's S Voice is a voice recognition application used to activate a wide variety of functions on your phone. This is a natural language recognition application.

This goes beyond the Google Search Voice Actions feature that simply recognizes Google commands and search terms. You can ask it questions (Is it raining in Dallas?) or give it commands (Show me where to find cheap gas).

1. Press  and tap  **Apps** >  **S Voice**.
2. Navigate through the following onscreen tutorial screens by reading the information and tapping **Next**, or tap **Skip** to continue without reading the information.
3. Wake up the application by speaking the phrase "Hi Galaxy."

Note: You can change the wake-up command/phrase from "Hi Galaxy" to anything else.

4. Tap **Speak** if the phone does not hear you or to give it a command.

Voice Recorder

The Voice recorder allows you to record an audio file up to one minute long and then immediately share it using Bluetooth, Dropbox, Email, Gmail, Group Cast, Messaging, or Wi-Fi Direct. Recording time will vary based on available memory.

- Press  and tap  **Apps** >  **Voice Recorder**.

VPN Client

VPN Client provides support for accessing VPN gateways.

- Press  and tap  **Apps** >  **VPN Client**.

Wallet

Google Wallet allows you to carry credit cards and debit cards in your Android phone. To use this app, tap the back of your phone at the point of sale to pay or shop online everywhere you see the Google Wallet Buy button.

- Press  and tap  **Apps** >  **Wallet**.

Settings

The following topics provide an overview of items you can change using your phone's Settings menus.

Access Settings

Settings are arranged on tabs by category, to quickly access options.

1. Press  and then tap  > **Settings**.
2. Tap a tab to access settings by category:
 -  **Connections:** Connect to wireless networks, including 3G, 4G, and Wi-Fi, and to other devices.
 -  **My device:** Personalize your phone, including sounds and the display, accessibility, and input.
 -  **Accounts:** Set up accounts on your phone, like your Google and Samsung accounts, and your email and social networking accounts. You can also set up backup options.
 -  **More:** Set permissions for locations and security, and manage your device.

Wi-Fi Settings

Use Wi-Fi settings to control your phone's connections to Wi-Fi networks, and for using Wi-Fi Direct to connect directly to other Wi-Fi Direct devices.

Turn Wi-Fi On or Off

When Wi-Fi is turned On, your device will notify you of available Wi-Fi networks, and you can connect to the Wi-Fi networks. Turn Wi-Fi Off when not in use, to conserve battery power.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap the **ON/OFF** switch beside **Wi-Fi** to turn Wi-Fi On or Off.

Note: You can also turn Wi-Fi On or Off from Notifications. Drag down from the top of the screen, and then tap the Wi-Fi button.

Configure Wi-Fi Settings

Set up and manage wireless access points.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap **Wi-Fi**, and then tap the **ON/OFF** switch beside **Wi-Fi** to turn Wi-Fi On. Wi-Fi must be On to configure settings.
3. Configure these settings:
 - **Add Wi-Fi network:** Connect to a new Wi-Fi network.
 - **Scan:** Search for available Wi-Fi networks.
 - **Wi-Fi Direct:** Connect to other Wi-Fi Direct devices.

Other Wi-Fi Settings

Set up and manage wireless access points.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap **Wi-Fi**, and then tap the **ON/OFF** switch to turn Wi-Fi On. Wi-Fi must be On to configure settings.
3. Tap  to configure these settings:
 - **Advanced:**
 - **Network notification:** When enabled, your phone alerts you when a new Wi-Fi network is available.
 - **Sort by:** Choose a sorting order for Wi-Fi networks on the Wi-Fi screen.
 - **Keep Wi-Fi on during sleep:** Specify when to switch from Wi-Fi to mobile data for data communications, when the device goes to sleep (when the backlight goes out). This setting can affect data usage, since the data connection will remain active even when the phone screen is off.
 - **Always allow scanning:** When enabled, your phone will allow Google location service and other apps to scan for networks, even when Wi-Fi is turned off.
 - **Auto network switch:** When enabled, your phone will automatically switch between known Wi-Fi networks and mobile networks. Known Wi-Fi networks are those you have already connected to.
 - **Wi-Fi timer:** When turned On, your phone will automatically connect or disconnect from a Wi-Fi network, using the Starting time and Ending times you set.
 - **Install certificates:** If you have certificates stored on an installed optional memory card (not included), you can use this option to install the certificates.

- **MAC address:** (Not configurable) View your device's MAC address, needed for connecting to some secured networks.
- **IP address:** (Not configurable) View your device's IP address.
- **WPS push button:** Set up a connection to a WPS (Wi-Fi Protected Setup) router or other equipment.
- **WPN PIN entry:** (Not configurable) View the PIN used by your device to set up a PIN-secured connection to a Wi-Fi router or other equipment.

Wi-Fi Direct

Wi-Fi Direct allows devices to connect to each other directly via Wi-Fi, without a Wi-Fi network or hotspot, and without having to set up the connection. For example, your device can use Wi-Fi Direct to share photos, contacts and other content with other Wi-Fi Direct devices.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap **Wi-Fi**, and then tap the **ON/OFF** switch beside **Wi-Fi** to turn Wi-Fi On. Wi-Fi must be On to configure Wi-Fi Direct settings.
3. Tap **Wi-Fi Direct** at the bottom of the screen. Your device automatically scans for nearby Wi-Fi Direct devices, or you can tap **Scan** to start scanning.
4. After scanning for devices, select a device, and then follow the prompts to complete the connection.

– or –

Touch **Multi-connect** to create a connection to devices that support multi-connect.

Touch **Scan** to search for available multi-connect devices, and then select the devices and follow the prompts to complete the connection.

Bluetooth Settings

Bluetooth is a short-range wireless communications technology for exchanging information over a distance of about 30 feet. You don't need to line up the devices to send information with Bluetooth. If the devices are in range, you can exchange information between them, even if they are in different rooms.

Your device can use Bluetooth to share photos, contacts and other content with other Bluetooth devices. Many of the apps on your device provide options for sharing via Bluetooth under  **Menu**.

Turn Bluetooth On or Off

When Bluetooth is On, you can scan and find other Bluetooth devices to share information between the devices. Turn Bluetooth Off when not in use to conserve battery power.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap the **ON/OFF** switch beside **Bluetooth** to turn Bluetooth On or Off.

Note: You can also turn Bluetooth On or Off from the Notification panel. Drag down from the top of the screen, and then tap the Bluetooth button.

Configure Bluetooth Settings

Pair with other Bluetooth devices, manage your Bluetooth connections, and control your device's visibility to other devices.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap **Bluetooth**, and then tap the **ON/OFF** switch to turn Bluetooth On. Bluetooth must be On to configure settings.
3. From the Bluetooth screen, configure these settings:
 - Tap the **ON/OFF** switch to turn Bluetooth On or Off.
 - Tap your device's name to enable or disable visibility to other Bluetooth devices. When your device is visible, other devices can find your devices during a scan. Your device remains visible for the period of time set in the Visibility timeout setting.
 - Tap a paired device to connect to it, or touch  beside a device to change its settings.
 - Tap **Scan** to search for visible Bluetooth devices. After searching, tap a device to pair with it.
4. Tap  for more settings:
 - **Visibility timeout:** Set the length of time your device is visible to other devices when you turn on visibility.
 - **Received files:** View files transferred to your device via Bluetooth.

Data Usage Settings

Monitor data usage, and control your device's connection to mobile data service.

Note: Data is measured by your phone. Your service provider may account for data usage differently.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap **Data usage** to configure options:
 - **Mobile data:** Enable or disable Mobile data. You can also control Mobile Data at Notifications.
 - **Limit mobile data usage:** When enabled, your mobile data connection will be disabled when the specified limit is reached. After enabling the setting, drag the red limit line on the graph below to set the data usage limit.
 - **Alert me about data usage:** When enabled, your device will alert you when mobile data usage reaches the warning limit you set. After enabling the setting, drag the orange warning line on the graph below to set the data usage warning limit.
 - **Data usage cycle:** Tap the menu, and then choose a time period for data usage. Data usage for the period displays on the graph, along with usage by application below.
3. Tap  to set other options:
 - **Restrict background data:** Your device is capable of connecting to the network in the background, for synchronization or other services. When enabled, background connections will not occur.
 - **Auto sync data:** When enabled, your device will synchronize with accounts automatically, at any time.
 - **Show Wi-Fi usage:** When turned On, a separate tab displays data usage while connected to Wi-Fi.
 - **Mobile hotspots:** Select Wi-Fi networks that are mobile hotspots. You can restrict apps from using these networks, and you can configure apps to warn you before using these networks for large downloads.

More Networks Settings

The More networks menu provides additional wireless and network options.

Airplane Mode

Enabling Airplane mode turns off calling, messaging, and data network features. It also turns off other connectivity features, such as Wi-Fi and Bluetooth.

While in Airplane mode, the  icon displays in the Status bar. While in airplane mode, you can use other features of your device, such as playing music, watching videos, or other applications.

To use Wi-Fi and Bluetooth when Airplane mode is enabled, turn them on in Settings, or on the Notifications panel.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap **More networks**, and then tap the check box next to **Airplane mode** to enable or disable the option.

Note: You can also control Airplane mode from the **Device options** menu. Press and hold the **Power/Lock Key**, and then tap **Airplane mode**.

Mobile Networks

Control your phone's access to networks, including mobile data service.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap **More networks** > **Mobile networks** to configure options:
 - **Mobile data:** When enabled, your device connects to the mobile data network.
 - **Network mode:** Choose a preferred network mode.
 - **Connections optimizer:** When enabled, helps you manage and enhance your data experience by finding and connecting to remembered Wi-Fi networks on your device, and, if applicable, to 4G network service.

VPN

Set up and manage Virtual Private Networks (VPN).

Note: VPN settings include storage of login credentials on your device. You must configure a screen unlock pattern, PIN or password before setting up a VPN.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap **More networks** > **VPN**, and then tap  to add a VPN. Depending on the type of VPN, this may include these options:
 - **Name:** Enter the name of the VPN.

- **Type:** Choose the type of VPN, from PPTP, L2TP/IPSec PSK, L2TP/IPSec RSA, IPSec Xauth PSK, IPSec Xauth RSA, or IPSec Hybrid RSA.
- **Server address:** Enter the VPN server address.
- **PPP Encryption (MPPE):** Tap to enable, if applicable for the VPN.
- **Show advanced options:** Tap to set other options, depending on the type of VPN.

3. Tap **Save** to save the VPN.

NFC Settings

Use NFC (Near Field Communication) to share information between your device and another NFC device by touching the devices together, typically back-to-back.

NFC is used with S Beam and Android Beam, and must be turned On to use these features.

Turn NFC On or Off

Use NFC (Near Field Communication) to share information between your device and another NFC device or NFC tag, by touching the devices together, typically back-to-back.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap the **ON/OFF** switch beside **NFC** to turn NFC On or Off.

Android Beam

With Android beam, you can transmit app content via NFC to other NFC devices that support Android Beam.

Android Beam uses NFC, so NFC must be turned On before you can turn on Android Beam.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap the **ON/OFF** switch beside **NFC** to turn NFC On. NFC must be on to use Android Beam.
3. Tap **NFC** to access Android Beam settings, and then tap the **ON/OFF** switch beside Android Beam to turn Android Beam On or Off.

S Beam Settings

Share more and share it faster with S Beam. From photos to documents, large video files to maps, you can share almost anything instantly with one touch, simply by placing your devices back-to-back.

S Beam uses your device's NFC (Near Field Communication) feature to send, or "beam", content to other NFC devices.

S Beam works in the background. Use the sharing options from your favorite apps to select content to share via S Beam. For example, you can beam pictures or videos from Gallery, or songs from Music player. Just bring the devices together (typically back to back), and then tap the screen.

Turn S Beam On or Off

When S Beam is turned On, you can send or receive data by touching your device to another NFC-capable device.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap the **ON/OFF** slider beside **S Beam** to turn S Beam On or Off.

Nearby Devices

Share files with devices using DLNA (Digital Living Network Alliance) standards, over Wi-Fi.

To use Nearby devices, you must connect to the same Wi-Fi network as the devices you wish to share with, and the other devices must support DLNA.

Note: Use care when enabling file sharing. When enabled, other devices can access data on your device.

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap **Nearby devices** to configure these options:
 - Tap the **ON/OFF** switch beside **Nearby devices** to turn Nearby devices On.
 - Under **Advanced**, touch options to control how content is shared from your device:
 - **Shared contents:** Choose the type of content to share, from Videos, Photos, or Music.
 - **Allowed devices list:** View and manage a list of devices allowed to connect to your device.
 - **Not-allowed devices list:** View and manage a list of devices restricted from connecting to your device.
 - **Download to:** Choose a location to save downloaded content, from USB storage (device memory) or optional installed SD card (not included).
 - **Upload from other devices:** Choose how to handle incoming files from other devices, from Always accept, Always ask, or Always reject.

Screen Mirroring Settings

With Screen mirroring, you can share your device's screen with another device, using an optional AllShare Cast accessory (not included).

Turn Screen Mirroring On or Off

1. Press  and then tap  > **Settings** > **Connections**.
2. Tap **Screen mirroring**, and then tap the **ON/OFF** switch beside Screen Mirroring to turn Screen mirroring On or Off.

Note: Tap  > **Help** to find instructions for using Screen mirroring to connect to a device.

Lock Screen

Configure settings for locking the screen, to improve security.

Screen Lock

Choose a screen lock, to dim and lock the screen.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Lock screen** > **Screen lock**.
3. Choose settings:
 - **Swipe:** When enabled, you unlock the device by swiping your finger across the screen. This is the default screen lock, and offers no security, but you can set special lock screen options.
 - **Face unlock:** When enabled, you unlock the device by looking at the screen. This option offers low security, because someone who looks similar to you could unlock your device. Tap the option for more information, and to set up Face unlock.
 - **Face and voice:** When enabled, you unlock the device by looking at the screen and speaking. This option offers low security, because someone who looks and/or sounds similar to you could unlock your device. Touch the option for more information, and to set up Face and voice unlock.
 - **Pattern:** When enabled, you draw a pattern, which you create, on the screen to unlock the device. Touch the option, and then follow the prompts to create or change your screen unlock pattern.
 - **PIN:** When enabled, you enter a numeric PIN (Personal Identification Number), which you create, to unlock the device. With PIN screen lock, you can also set the With swipe lock and Lock screen options.

- **Password:** When enabled, you enter an alphanumeric password, which you create, to unlock the device.
- **None:** Disable all custom screen lock settings, to use the default swipe unlock screen.

Lock Screen Options

When you have a screen lock set, you can set Lock screen options. Available options depend on the type of screen lock.

Multiple Widgets

When Multiple widgets is enabled, more than one widget can be displayed on the lock screen

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Lock screen**, and then tap **Multiple widgets** to enable or disable the option.

Lock Screen Widgets

You can choose widgets to display on the lock screen, for easy access to features, even when the screen is locked.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Lock screen** > **Lock screen widgets** to configure these options:
 - Tap **Clock or personal message** to choose whether to display a Clock, or a personal message, on the Lock screen. Depending on the option you choose, you can then customize:
 - **Clock widget options:** When Clock is selected, tap **Dual clock** to display a dual clock when traveling, to show the time in your home area, and the current location. You can also set the size of the clock, and set options showing the date and Owner information.
 - **Edit personal information:** When Personal message is selected, tap to create a personal message to display on the lock screen.

Shortcuts

You can choose to have app shortcuts display on the lock screen, and choose the apps to display. This option is available when the Swipe screen lock is set.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Lock screen** > **Shortcuts** to configure options:

- Tap the **ON/OFF** switch beside **Shortcuts** to turn the option On or Off. The option must be on to configure apps to display.
- Tap default shortcuts to replace them with a new app shortcut you choose.

Make Pattern Visible

When you have a Pattern screen lock set, you can choose whether the pattern is visible briefly as you draw it on the lock screen. This option is available when the Pattern screen lock is set.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Lock screen**, and then tap the check box beside **Make pattern visible** to turn the option On or Off.

Lock Automatically

When you have a screen lock set, you can choose a time period for automatically locking the screen after the screen turns off, or choose to have the screen lock immediately when the screen turns off.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Lock screen**, and then tap **Lock automatically** to choose a time lock setting.

Lock Instantly With Power Key

When enabled, pressing the Power Key locks the screen immediately.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Lock screen**, and then tap the check box beside **Lock instantly with power key** to turn the option On or Off.

Unlock Effect

When enabled, swiping your finger across the lock screen displays an effect.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Lock screen**, and then tap **Unlock effect** to choose Ripple effect, Light effect, or None.

Help Text

When enabled, helpful tips display on the lock screen.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Lock screen**, and then tap **Help text** to turn the option on or off.

Wake Up In Lock Screen

When enabled, you can press the  **Home Key**, and then speak a wake-up command to unlock the screen. This option is available when the Swipe screen lock is set.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Lock screen**, and then configure these options:
 - **Wake up in lock screen:** Tap to enable or disable the option.
 - **Set wake-up command:** When Wake up in lock screen is enabled, set options for wake-up commands.

Display Settings

Configure settings for your phone's display.

Wallpaper

Customize the background of the Home and Lock screens. Choose from preloaded wallpapers. or select a photo you have downloaded or taken with the Camera.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Display** > **Wallpaper**.
3. Tap a screen to customize, from **Home screen**, **Lock screen**, or **Home and lock screens**.
4. Choose a source for wallpaper:
 - **Gallery:** Select a picture from Gallery. Follow the prompts to crop the picture and save it as wallpaper.
 - **ID wallpapers:** Select an image from an ID pack. (Home screen only).
 - **Live wallpapers:** Select a moving scene for the background (Home screen only).
 - **Wallpapers:** Choose an image from the Wallpapers gallery.

Notification Panel

Configure options for the Notification panel, available when you swipe your finger down from Status bar at the top of the screen.

At the top of the Notification panel, you can control settings with the Quick setting buttons. Choose quick setting buttons in Notification panel settings.

1. Press  and then tap  > **Settings** > **My device**.

2. Tap **Display > Notification panel**.
3. Configure settings:
 - **Brightness adjustment:** Tap the check box to display a slider for adjusting the screen brightness on the notification panel.
 - **Set the quick setting buttons:** Quick setting buttons display at the top of the Notification panel, to allow you to set favorite options quickly.
 - Tap buttons to add or hide the button from the Notification panel.
 - Touch and hold a button, and then drag it into a new position in the list.

Multi Window

Multi window allows you to use two apps on the same screen, in separate, resizable windows.

You can enable Multi window in Settings, and then control whether it displays on the screen by touching and holding on the  **Back Key**.

1. Press  and then tap  > **Settings > My device**.
2. Tap **Display**, and then tap the check box beside **Multi window** to enable or disable the option.

Page Buddy

When Page buddy is turned On, your phone displays context-related pages on the Home screen, depending on device status.

For example, if you plug optional earphones into your phone's 3.5mm Headset Jack, your phone can display a special page with music playback controls.

1. Press  and then tap  > **Settings > My device**.
2. Tap **Display > Page buddy**.
3. Configure options:
 - Tap the **ON/OFF** switch to turn Page buddy On or Off.
 - Tap features to configure:
 - **Earphones page:** When enabled, a special page displays when you plug optional earphones (not included) into the 3.5mm Headset Jack.
 - **Docking page:** When enabled, a special page displays when you place the phone into an optional dock accessory (not included).

Note: Tap **Page buddy help** for more information.

Brightness

Adjust your screen's brightness to suit your surroundings.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Display** > **Brightness** to configure options:
 - Tap the check box next to **Automatic brightness** to allow the phone to adjust brightness automatically.
 - To set a custom brightness level, clear the Automatic brightness checkmark and then touch and drag the **Brightness level**.
3. Tap **OK** to save the settings.

Auto Rotate Screen

When Auto rotate screen is enabled, the screen automatically updates when you rotate the phone. See [Rotate](#) for more information.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Display**, and then tap the check box next to **Auto rotate screen** to turn the feature On or Off.

Note: You can also control screen rotation from Notifications, with the Screen rotation setting.

Screen Timeout

Screen timeout lets you select how long the display screen remains lit after you press any key.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Display**, and then tap **Screen timeout** to choose a time period.

Daydream

The Daydream setting controls what the screen displays when the phone is docked, or while charging. You can choose to display a Colors screen, or display photos stored on your phone.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Display**, and then tap the **ON/OFF** switch next to **Daydream** to turn the option On or Off. When On, you can configure these options:
 - **Colors:** Tap the selector to enable or disable display of a colorful screen.
 - **Flipboard:** Display pictures from Flipboard. After enabling the option, tap  to choose pictures to display.

- **Photo Frame:** Display pictures in a photo frame. After enabling the option, tap  to choose pictures to display.
- **Photo Table:** Display of pictures in a photo table. After enabling the option, tap  to choose pictures to display.
- Tap **Start now** to switch to daydream.
- Tap **Select dream time** to choose when daydream displays.

Font Style

You can set the font for all text that displays on the screen.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Display**, and then tap **Font style** to choose a font. Follow the prompts to set it as the default.

Tip: To find additional font options, tap **Get fonts online** to access new fonts in the Google Play Store app.

Font Size

This option allows you to select the size of fonts for your phone's screens.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Display**, and then tap **Font size** to select a size.

Touch Key Light Duration

This feature allows you to set the length of time the  and  touch keys on the front of your phone remain lit after you tap them.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Display**, and then tap **Touch key light duration** to choose a duration period.

Display Battery Percentage

The battery charge level displays as an icon in the notification panel by default. This feature allows you to display the battery icon plus the percentage of remaining charge.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Display**, and then tap the check box beside **Show battery percentage** to enable or disable the option.

Auto Adjust Screen Tone

When Auto adjust screen tone is enabled, your device automatically analyzes the screen and adjusts the brightness to conserve battery power.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Display**, and then tap the check box beside **Auto adjust screen tone** to enable or disable the option.

LED Indicator Settings

The LED indicator on the front of the device displays when the device is locked, to notify you of status changes and events. Use LED indicator settings to configure how the LED functions.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **LED indicator**, and then tap the check box beside options to enable or disable the option:
 - **Charging**: When enabled, the LED glows red during charging, and green when the battery is fully charged.
 - **Low battery**: When enabled, the LED blinks red to indicate low battery charge.
 - **Notifications**: When enabled, the LED blinks blue to show that you have missed calls, new messages, or application events.
 - **Voice recording**: When enabled, the LED blinks blue when recording with the screen turned off.

Sound Settings

Use Sound settings to control your phone's audio, from ringtones and alerts to touch tones and notifications.

Volume

You can adjust the volume settings to suit your needs and your environment.

Note: You can quickly adjust the ringer volume or the earpiece volume during a call by pressing the **Volume Key**.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap **Volume** to set volume levels. Drag the sliders to set the default volume for:
 - **Music, video, games, and other media**

- **Ringtone**
- **Notifications**
- **System**

3. Tap **OK** to assign the volume levels.

Vibration Intensity

Set the level for vibration to accompany ringtones and notifications.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap **Vibration intensity** to set vibrations. Drag the sliders to set the vibration intensity for:
 - **Incoming call**
 - **Notification**
 - **Haptic feedback**
3. Tap **OK** to save the settings.

Ringtones

Choose a ringtone for incoming calls.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap **Ringtones** to choose a ringtone:
 - Tap a ringtone to select it. As you tap a ringtone, a sample plays.
 - Tap **Add** to choose a music track from Google Music, a sound file from Dropbox, or use Sound picker to choose a song from Music player.
3. Tap **OK** to save the setting.

Vibrations

Choose vibrations to play for notifications, such as for incoming calls, new messages, and event reminders.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap **Vibrations** to choose a notification tone.
3. Tap a vibration to play a sample and select the vibration, or tap **Create** to create your own pattern.

4. Tap **OK** to save the setting.

Default Notification Sound

Choose a sound for notifications, such as for new messages and event reminders.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap **Default notification sound** to choose a notification tone.
3. Tap a sound to play a sample and select the sound.
4. Tap **OK** to save the setting.

Vibrate When Ringing

When Vibrate when ringing is enabled, a vibration plays for calls and notifications, along with the ringtone or sound. You can use the Vibration intensity and Vibrations settings to customize the vibration.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap the check box next to **Vibrate when ringing** to enable or disable the option.

Dialing Keypad Tone

When Dialing keypad tone is enabled, tones play when you tap keys on the Phone keypad.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap the check box next to **Dialing keypad tone** to enable or disable the option.

Touch Sounds

When Touch sounds is enabled, tones play when you tap or touch the screen to make selections.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap the check box next to **Touch sounds** to enable or disable the option.

Screen Lock Sound

When Screen lock sound is enabled, tones play when you touch the screen to lock or unlock it.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap the check box next to **Screen lock sound** to enable or disable the option.

Haptic Feedback

When Haptic feedback is enabled, vibration plays when you tap the Menu and Back keys, and for certain screen touches.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap the check box next to **Haptic feedback** to enable or disable the option.

Auto Haptic

When Auto haptic is turned On, the device vibrates automatically in response to the sounds of some apps, such as games.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap the **ON/OFF** switch next to **Auto haptic** to turn the feature On or Off.

Emergency Tone

You can choose to have a tone play, or have your phone vibrate, periodically during an emergency call.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap **Emergency tone** to select a tone:
 - **Off**: No tone or vibration plays during emergency calls.
 - **Alert**: A tone plays during emergency calls.
 - **Vibrate**: A vibration plays during emergency calls.

Samsung Keyboard Settings

You can choose whether sounds and vibrations play when you tap keys on the Samsung Keyboard while entering text.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap an option to enable or disable it:
 - **Key-tap sound**: When enabled, a sound plays when you tap keys.
 - **Key-tap vibration**: When enabled, a vibration plays when you tap keys.

HDMI Audio Output

Choose the type of sound output when you attach your phone to another device via HDMI cable.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Sound**, and then tap **Audio output** to choose whether sound is output as Stereo or Surround.

Home Screen Mode Settings

Your phone offers two Home screen modes:

- **Standard mode** provides a conventional layout for apps and widgets on the Home screen.
- **Easy mode** provides an easier experience for the first-time smartphone user.

You can choose the Home screen mode at any time.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Home screen mode**, and then choose a mode. Touch **Apply** to save your selection.

Call Settings

Configure options for calling with your phone.

Call Rejection

Create and manage a list of phone numbers, to have your device automatically reject calls you receive from those numbers.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap **Call rejection** to configure these options:
 - **Auto reject mode:** Tap the **ON/OFF** switch beside **Auto reject mode** to turn the option On or Off. When turned On, tap **Auto reject mode** to select a mode, from:
 - **All numbers:** Calls from all numbers are rejected.
 - **Auto reject numbers:** Calls from numbers on the Auto reject list are rejected.
 - **Auto reject list:** Enter telephone numbers, to reject calls from the numbers when Auto reject mode is turned On.
 - Tap  to enter a telephone number, or select a number from a contact. Tap **Match criteria** to set options for using the reject number list.
 - Tap the check box next to Unavailable to reject calls with numbers that display “Unavailable” in Caller ID.

Set Up Call Rejection Messages

Create and manage text messages to send to callers when rejecting incoming calls. Messages you create here are available from the incoming call screen when you use the Reject with message option.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap **Set up call rejection messages** to manage messages:
 - To create new messages, tap **Create**, and then follow the prompts.
 - To modify an existing message, tap the message, and then edit the text.

Answering/Ending Calls

Manage settings for answering and ending calls.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap **Answering/ending calls** to configure these options:
 - **The home key answers calls:** When enabled, you can answer incoming calls by pressing the **Home Key**.
 - **Voice control:** When turned On, you can answer calls by speaking commands. Tap the **ON/OFF** switch to turn Voice control On, and then tap **Voice control** to configure the **Incoming calls** option. When enabled, you can answer or reject calls with the voice commands “Answer” and “Reject”. When you answer a call with a voice command, the Speaker will automatically turn on for hands-free calls.
 - **The power key ends calls:** When enabled, you can end calls by pressing the **Power/Lock Key**. In this case, pressing the power key during a call will not lock the screen.

Turn Off Screen During Calls

When enabled, the screen automatically turns off during phone calls, and the proximity sensor on the front of the device is used to turn the screen back on when the device is moved or brought close to another surface, such as when you move the device to your ear.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap **Turn off screen during calls** to enable or disable the setting.

Call Alerts

Set options for sounds and vibrations to occur during calls.

1. Press  and then tap  > **Settings** > **My device**.

2. Tap **Call**, and then tap **Call alerts** to configure settings:

- **Vibrate on connection to network:** When enabled, your phone will vibrate when a call connects to the network.
- **Call-end vibration:** When enabled, the phone vibrates when the other caller ends the call.
- **Call connect tone:** When enabled, the phone plays a tone when the other caller answers a call.
- **Minute minder:** When enabled, a tone plays once per minute during a call.
- **Call end tone:** When enabled, the device plays a tone when the other caller ends the call.
- **Alerts on call:** When enabled, notifications for alarms and new messages play during calls. When disabled, these notifications will be muted during a call.

Call Accessories

Configure options for using a headset for calling.

1. Press  and then tap  > **Settings** > **My device**.

2. Tap **Call**, and then tap **Call accessories** to configure settings:

- **Automatic answering:** When enabled, and you have a headset connected to the Headset Jack, incoming calls are answered automatically after a delay, which you can set at Automatic answering timer. Tap to enable or disable the setting.
- **Automatic answering timer:** Choose a time period to delay before automatically answering an incoming call when Automatic answering is enabled and a headset is connected to the device. Tap to choose **2 seconds**, **5 seconds**, or **10 seconds**.
- **Outgoing call conditions:** When the device is paired with a Bluetooth headset, you can choose to make calls even when the device is locked. Tap to choose **Even when device locked**, or **Only when device unlocked**.

Ringtones and Keypad Tones

Choose tones and vibrations to play for incoming calls and keypad taps.

1. Press  and then tap  > **Settings** > **My device**.

2. Tap **Call**, and then tap **Ringtones and keypad tones** to configure settings:

- Tap **Ringtones**, and then select a ringtone for incoming calls. Tap **OK** to save your selection.

- Tap **Vibrations**, and then select a vibration pattern to play for incoming calls when the Vibrate when ringing option is enabled. You can tap **Create** to create a custom pattern. Tap **OK** to save the settings.
- Tap **Vibrate when ringing** to play a vibration for incoming calls. The vibration pattern is set at the Vibrations setting.
- Tap the check box next to **Dialing keypad tone** to enable or disable tones for keypad taps.

Personalize Call Sound

Choose options for call audio, in cases where you might need the sound softer or more clear, or optimized for your right or left ear.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap **Personalize call sound**.
3. Tap a setting, and then configure options if available:
 - **In-call sound EQ**: Choose a setting for sounds during a call. You can choose soft or clear sound, or adapt sound to your left or right ear.
 - **Adapt sound**: Tap **Start**, and then follow the onscreen prompts to find the best sound for you.

Noise Reduction

When enabled, Noise reduction suppresses background noise from your environment during calls.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap **Noise reduction** to enable or disable noise reduction.

Increase Volume In Pocket

When enabled, this setting uses the proximity sensor to detect when the device is in a pocket or other close-fitting location such as a purse or bag, and increases the volume for incoming call ringtones.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap the check box **Increase volume in pocket** to enable or the setting.

US Dialing

When enabled, the US dialing option replaces “+” with the international access code for your location.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap the check box next to **US dialing** to enable or disable the setting.

International Dialing

When US dialing is enabled, it uses the International dialing code to replace “+”. US dialing must be disabled to access the International dialing code.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap the check box next to **US dialing** to disable the setting. US dialing must be disabled to access the International dialing setting.
3. Tap **International dialing**, and then use the keypad to enter the international dialing code.
4. Tap **OK** to save the code.

TTY Mode

A TTY (teletypewriter, also known as a TDD or Text Telephone) is a telecommunications phone that allows people who are deaf, hard of hearing, or who have speech or language disabilities, to communicate by telephone.

Your phone is compatible with select TTY phones. Please check with the manufacturer of your TTY phone to ensure that it supports digital wireless transmission. Your phone and TTY phone will connect using a special cable that plugs into your phone’s headset jack. If this cable was not provided with your TTY phone, contact your TTY phone manufacturer to purchase the connector cable.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap **TTY mode** to choose a mode, from **TTY Off**, **TTY Full**, **TTY HCO**, or **TTY VCO**.

DTMF Tones

Set the length of Dual-tone Multi-frequency (DTMF) tones, which play when you use the keypad during a call, such as when navigating menus.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap **DTMF tones** to choose a tone length, from **Normal**, or **Long**.

DDTM

When DDTM is enabled, you can make/receive voice calls or use voicemail while using mobile networks.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap **DDTM** to enable or disable the option.

Voicemail Settings

Set options for Visual Voicemail.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Call**, and then tap **Voicemail settings** to configure options for voicemail.

Blocking Mode Settings

When Blocking mode is enabled, notifications for selected features are blocked, and you only receive the notifications you choose. You can choose to block notifications by feature or contact, and choose blocking all the time, or during a specific time period.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap the **ON/OFF** switch next to **Blocking mode** to enable or disable the setting.
Blocking mode must be enabled to configure options.
3. When Blocking mode is enabled, choose features to block:
 - **Block incoming calls:** When enabled, notifications for incoming calls will not display. Tap the check box next to the option to enable or disable it.
 - **Turn off notifications:** When enabled, notifications for new messages will not display. Tap the check box next to the option to enable or disable it.
 - **Turn off alarm and timer:** When enabled, notifications for alarms and timers will not display. Tap the check box next to the option to enable or disable it.
 - **Turn off LED indicator:** When enabled, the LED indicator will not light for notifications, even when the screen is off. Tap the check box next to the option to enable or disable it.
4. Set a time period for blocking mode:
 - Tap the check box next to **Always**, to block notifications at all times.
 - To set a specific time period to block notifications each day, disable the **Always** option, and then set a starting (From field) time and ending time (To field). Tap the time fields and then set the time.
5. Choose an option for blocking by contact:
 - Tap **Allowed contacts**, and then choose an option:

- **None:** Block all notifications, from any contact.
- **All contacts:** Allow notifications from any contact.
- **Favorites:** Only allow notifications from contacts marked as favorites.
- **Custom:** Allow notifications from contacts you specify. Create a list of allowed contacts by tapping **Add**, and then selecting contacts from Contacts.
- If you have created a Custom list of allowed contacts, you can tap **Allowed contact list** to modify the list of allowed contacts. This option is only available when the Custom list is enabled.

Hands-free Mode Settings

Configure settings for using your phone without touching it, such as announcing incoming calls and reading out messages.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Hands-free mode**, and then tap the **ON/OFF** switch beside **Hands-free mode** to turn the feature On or Off.
3. After you turn the feature On, you can configure options:
 - **Incoming call:** When enabled, your phone reads out the caller's information when you receive a call.
 - **Message:** When enabled, your phone reads out the sender's information when you receive a message.
 - **Alarm:** When enabled, your phone reads out alarm information when an alarm sounds.
 - **Schedule:** When enabled, your phone reads out event information when a reminder sounds.

Power Saving Mode Settings

Configure Power saving mode settings to conserve battery power.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Power saving mode** to configure options:
 - Tap the **ON/OFF** switch next to **Power saving mode** to turn the mode On or Off. Power saving mode must be turned On to configure settings.

- **CPU power saving:** When enabled, the maximum performance of the device's CPU (Central Processing Unit) is disabled to conserve battery power. Tap the check box beside the option to enable or disable it.
- **Screen power saving:** When enabled, the frame refresh rate and brightness level are reduced to conserve power. Tap the check box beside the option to enable or disable it.
- **Turn off haptic feedback:** When enabled, Haptic feedback is disabled to conserve battery power. Tap the check box beside the option to enable or disable it.

Note: Tap **Learn about Power saving** to view information about these settings.

Accessory Settings

Configure your device's behavior when it is connected to an optional dock (not included).

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Accessory** to configure settings:
 - **Dock sound:** When enabled, a sound plays when you insert and remove the device from the dock.
 - **Audio output mode:** When enabled, audio plays through the dock speakers when the device is docked.
 - **Desk home screen display:** When enabled, displays a special screen when the device is docked.
 - **Audio output:** Choose a destination for audio output when you connect to devices via HDMI cable.

Accessibility Settings

Your device offers features to make using the device easier for those with certain physical disabilities. Use Accessibility settings to configure these features.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Accessibility** to configure options:
 - Tap **Auto rotate screen** to enable or disable automatic rotation of the screen when you rotate the phone.
 - Tap **Screen timeout** to set a period of time for the screen to remain lit, after which it will dim and lock.
 - Tap **Speak passwords** to allow the phone to read aloud password information.

- Tap **Answering/ending calls** to configure various ways to answer or end calls.
- Tap **Show shortcut** to display a shortcut to Accessibility settings on the Device options menu. The Device options menu displays when you press and hold the **Power/Lock Key**.
- **Services:**
 - Tap **TalkBack** to activate the TalkBack feature and configure options.
- **Vision:**
 - Tap **Font size** to change the size of the fonts used on the screen. Choose **Tiny**, **Small**, **Normal**, **Large**, or **Huge**.
 - Tap **Magnification gestures** to control whether your phone recognizes gestures to pan, and zoom in or out.
 - Tap **Negative colors** to reverse the display of onscreen colors from White text on a Black background to Black text on a White background.
 - Tap **Accessibility shortcut** to control whether your device recognizes a gesture to quickly enable accessibility features. To use the gesture, press and hold the **Power/Lock Key** until you hear a sound or feel a vibration, and then touch and hold two fingers on the screen until you hear an audio confirmation.
 - Tap **Text-to-speech options** to configure options for converting text to speech. For more information, see [Text-to-speech Options](#).
- **Hearing:**
 - Tap **Sound Balance** to control the signal sent to the left and right when using earphones.
 - Tap the check box next to **Mono audio** to enable stereo audio to be compressed into a single mono audio stream for use with a single earphone.
 - Tap the check box next to **Turn off all sounds** to mute every sound made by the phone.
 - Tap the check box next to **Flash notification** to have your phone blink the Camera flash for notifications.
- **Mobility:**
 - Tap the check box next to **Press and hold delay** to choose how long your phone waits when you hold your finger on the screen, before continuing with the tap and hold action.

Language and Input Settings

Use Language and input settings to choose a default language for your phone's operations, plus settings for text entry and other inputs..

Choose a Default Language

Choose the language for operating your phone.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Language and input**, and then tap **Language** to select a language.

Set a Default Input Method

The following procedure allows you to select and set the default method you will use when accessing the keyboard.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Language and input**, and then tap **Default** to select the default input method.

Google Voice Typing Settings

Google voice typing allows you to speak your entries. When you enable Google voice typing, it's available for use when you touch a field to enter text..

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Language and input**, and then tap the check box next to **Google voice typing** to enable or disable the feature.
3. Tap  beside **Google voice typing** to configure options:
 - **Choose input languages:** Select language(s) to use for voice input, or choose Automatic to let Google decide.
 - **Block offensive words:** allows you to hide recognized offensive words.
 - **Offline speech recognition:** Download and install speech recognition engines, to allow you to use voice input while not connected to the network, such as during Airplane mode.

Samsung Keyboard

The Samsung Keyboard is an onscreen QWERTY keyboard, so you can enter text by “typing” on the keyboard. Samsung keyboard is enabled by default, and you can choose options for using it.

1. Press  and then tap  > **Settings** > **My device**.

2. Tap **Language and input**, and then tap  next to **Samsung keyboard** to configure these options:
- **Input languages:** Tap **Select input languages** to choose language(s) for use with Samsung keyboard. When you have more than one language enabled, you can slide your finger on the space bar while entering text to switch languages.
 - **Predictive text:** Tap the **ON/OFF** switch to turn predictive text On or Off. Predictive text suggests words matching your text entries, and optionally, completes common words automatically. Tap **Predictive text** to configure options:
 - **Personalized data:** When enabled, predictive text uses personal language data you have entered to make better predictions. Samsung keyboard can collect all the text you enter, including personal data and credit card numbers, in order to give better prediction results.
 - **Learn from Gmail:** Log into Gmail to allow your device to learn from your Gmail email.
 - **Learn from Facebook:** Log into Facebook to allow your device to learn from your Facebook postings.
 - **Learn from Twitter:** Log into Twitter to allow your device to learn from your Twitter postings.
 - **Learn from Messages:** Allow your device to learn from your text and multimedia messages.
 - **Learn from Contacts:** Allow your device to learn from your Contacts entries.
 - **Clear personal data:** Remove all personalized data you have entered.
 - **Auto replacement:** When turned On, predictive text will complete or replace the word you are typing with the most probable word when you tap the Space bar or a punctuation mark.
 - **Auto capitalization:** When enabled, predictive text automatically capitalizes words in your text based on common usage, such as at the beginning of sentences.
 - **Auto spacing:** When enabled, predictive text automatically inserts spaces between words.
 - **Auto punctuate:** When enabled, a period and space are automatically entered to end a sentence, when you tap the space bar twice.
 - **Keyboard swipe:** When enabled, you can enter text by sliding your finger across the keys on the keyboard.

- **None:** When enabled, Samsung Keyboard will not accept text entry by swiping.
- **T9 Trace:** When enabled, you can enter text by swiping your finger across the keyboard.
- **Cursor control:** When enabled, you can slide your finger across the keyboard to move the cursor to begin entering text.
- **Key-tap feedback:** Enable or disable options for sound or vibration feedback to your onscreen keyboard touches.
 - **Sound:** When enabled, a sound plays for your key touches.
 - **Vibration:** When enabled, a vibration plays for your key touches.
 - **Character preview:** When enabled, the character appears in a bubble as you tap keys.
 - **Tutorial:** Learn about Samsung Keyboard.
 - **Reset settings:** Return settings to the defaults.

Swype Settings

Swype is a new way to enter text on touch screens. Instead of touching each key individually, use your finger to trace over the letters of a word. For each word, place your finger on the first letter and glide to the subsequent letters, lifting on the last letter.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Language and input**, and then tap  next to **Swype** to configure these options:
 - **Settings:** Set Swype options:
 - **Vibrate on keypress:** When enabled, the device vibrates for your Swype touches.
 - **Sound on keypress:** When enabled, the device plays sounds for your Swype touches.
 - **Pop-up on keypress:** When enabled, the characters display briefly as you tap keys.
 - **Show complete trace:** When enabled, Swype displays the trace of each word until you start the next word.
 - **Auto-capitalization:** When enabled, Swype automatically capitalizes the first word of sentences.

- **Auto-spacing:** When enabled, Swype automatically inserts spaces between words as you complete them.
- **Next word prediction:** When enabled, Swype predicts the next word based on the previous word.
- **Show Voice key:** When enabled, a Voice input key displays on the Swype keyboard.
- **My Words:** Choose options for customizing Swype based on your text entries.
 - **Backup & Sync:** Use Swype Connect to back up your words.
 - **Living Language:** When enabled, Swype will automatically update with popular new words.
 - **Social integration:** Log in to your favorite social networking sites, to use your entries there to update Swype.
 - **Edit my dictionary:** Modify words added to Swype.
 - **Clear language data:** Delete all the words you've added to the Swype dictionary.
 - **Contribute usage data:** Allow Nuance to collect usage data to provide better text prediction.
 - **Cellular data:** When enabled, Swype can use your phone's connection to the wireless data network for updates, language downloads, and other Swype Connect features.
- **Languages:** Choose the current language for Swype, and download new languages to use with Swype.
- **Gestures:** Learn about shortcuts you can use on the keyboard to quickly accomplish common tasks.
- **Help:** Learn about using Swype.
 - **How to Swype:** Learn about using Swype.
 - **Show helpful tips:** When enabled, tips display on the screen as you enter text.
 - **Version:** Display the software version.
- **Updates:** Check for updates to Swype, and install them if desired.

Voice Search Settings

The Voice Search feature is a voice-activated application that allows you to tell the phone what to search for and then the phone activates a Google search based on what you said.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Language and input**, and then tap **Voice search** for these options:
 - **Language:** Choose a language for voice searching.
 - **Speech output:** Choose options for speech output.
 - **Block offensive words:** When enabled, words many people find offensive are not shown in results of Google voice searches. Offensive words are replaced in results with a placeholder (####).
 - **Hotword detection:** When enabled, you can say “Google” to launch voice search.
 - **Offline speech recognition:** Download speech recognition, to enable voice input while offline.
 - **Personalized recognition:** When enabled, Google uses your personalized information to improve speech recognition.
 - **Google Account dashboard:** Manage your collected data.
 - **Bluetooth headset:** Records audio through a Bluetooth headset, when using an optional Bluetooth headset (not included), paired with your phone.

Text-to-Speech Options

Text-to-speech (TTS) provides audible readout of text, for example, the contents of text messages and the Caller ID for incoming calls.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Language and input**, and then tap **Text-to-speech options** to configure options:
 - **Preferred TTS engine:** Select Samsung text-to-speech engine, or Google Text-to-speech Engine. Tap  to configure options.
 - **General:**
 - **Speech rate:** Choose a rate for text readouts.
 - **Listen to an example:** Play an example of speech used for readouts.

Pointer Speed

Adjust the speed of the pointer, when you use your finger to enter text.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Language and input**, and then tap **Pointer speed**.

3. Drag the slider to set the pointer speed, and then tap **OK** to save your selection.

Motion Settings

Configure Motion settings to control your device by moving it, or by hand gestures.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Motion** to configure features:
 - Tap the **ON/OFF** switch beside **Motion** to turn the feature On or Off. When Motion is turned On, you can enable or disable individual motions:
 - **Motion:**
 - **Direct call:** When enabled, you can lift the device to your ear while viewing a contact to call the contact.
 - **Smart alert:** When enabled, you can lift the phone to receive notifications of missed calls and notifications that occurred while the device was stationary.
 - **Double tap to top:** When enabled, you can tap the top of the phone twice to move to the top of a list.
 - **Tilt to zoom:** When enabled, you can tilt the phone to zoom in or out when viewing pictures in Gallery or viewing a web page.
 - **Pan to move icon:** When enabled, you can touch and hold an icon on the Home screen, and then move the phone in a side-to-side to move the icon to a new page.
 - **Pan to browse images:** When enabled, you can move the phone in a side-to-side motion while viewing an image to move around the image.
 - **Shake to update:** When enabled, you can shake the phone to scan for new devices, such as for a Bluetooth scan.
 - **Turn over to mute/pause:** When enabled, you can mute incoming calls and pause playback by turning the phone screen-side down.
 - **Sensitivity settings and tutorial:**
 - **Sensitivity settings:** Configure settings, such as calibrating the device's gyroscope, used to detect motion, and other motion options (when the options are enabled).
 - **Learn about motions:** Tap to view demonstrations of each motion.
 - **Hand motions:**

- **Palm swipe to capture:** When enabled, you can save a copy of the current screen by swiping the side of your hand across the screen.
- **Palm touch to mute/pause:** When enabled, you can mute incoming calls and pause playback by covering the screen with your hand.
- **Hand motion tutorial:**
 - **Learn about hand motions:** Tap to see demonstrations of hand motions.

Smart Screen Settings

Use Smart screen options to have your phone automatically adjust screen timeout, rotation when it detects you are looking at the screen, and control scrolling and playback based whether you are facing the screen.

Smart screen options use the front camera to detect when you are facing the screen. Some factors that may affect the ability of the front camera to detect your face are:

- When the phone is not docked or held upright, for example when placed on a table.
- When the front camera cannot detect your face and eyes.
- When the front camera is being used for the current application.
- When the source of light is behind you, or when using the phone in the dark.

Smart Stay

When Smart stay is enabled, the screen will not time out as long as you are looking at it.

When enabled, the Smart stay icon  displays in the Status bar.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Smart screen**, and then tap the check box beside **Smart stay** to enable or disable the option.

Smart Rotation

When Smart rotation is enabled, the screen automatically updates to match the angle at which you are viewing.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Smart screen**, and then tap the check box beside **Smart rotation** to enable or disable the option.

Voice Control Settings

When Voice control is turned On, you can use voice commands to control your phone.

Note: If you set the alert type for calls or notifications to vibrate, voice command is not available.

1. Press  and then tap  > **Settings** > **My device**.
2. Tap **Voice control**, and then tap the **ON/OFF** switch beside **Voice control** to turn the feature On or Off.
3. After you turn the feature On, tap **Voice control** to set options:
 - **Incoming calls:** When enabled, you can answer or reject calls with the voice commands “Answer” and “Reject”. When you answer a call with the voice command, the Speaker will automatically be turned on for hands-free talking.
 - **Alarm:** When enabled, you can stop or snooze alarms with the voice commands “Stop” and “Snooze”.
 - **Camera:** When enabled, you can take pictures with the voice commands “Smile”, “Cheese”, “Capture” and “Shoot”.
 - **Music:** When enabled, you can control the music player with the voice commands “Next”, “Previous”, “Pause”, “Play”, “Volume Up”, and “Volume Down”.

Accounts Settings

When you set up accounts on your phone, such as your Google or Samsung accounts, and your email or social networking accounts, you can synchronize account information between your phone and the account. Types of information you can synchronize include contacts, pictures, videos, and other types of files.

You can also set up options for backing up information from your phone to the cloud, and back up or reset your device.

Add an Account

Add an account to your phone to share information between your phone and the account.

1. Press  and then tap  > **Settings** > **Accounts**.
2. Choose a type of account, and then follow the prompts to enter your account credentials and complete the account set up.

Backup Options

Set up a backup account on your phone to save information from your phone to the account.

1. Press  and then tap  > **Settings** > **Accounts**.

2. Tap an option to configure backup features:

- **Cloud:** Configure options for synchronizing and backing up information.
 - **Add account:** Sign in to your Samsung account, or create a new Samsung account. You can sync contacts, calendar events, memos, and Internet shortcuts. You can back up Logs, SMS and MMS messages, and current wallpaper settings.
 - **Link Dropbox account:** Sign in to your Dropbox account, or set up a new account, to sync pictures, videos and documents.
- **Backup and reset:** Configure options for backing up data from your phone to a Google account.
 - **Back up my data:** Tap the check box to turn On automatic backup to a Google account, and then set up an account for the backups.
 - **Backup account:** When Back up my data is turned On, set up a Google account for backups. You can set up a new Google account, or sign in to an existing account.
 - **Automatic restore:** When Back up my data is turned On, you can also turn on Automatic restore to automatically restore settings and other information from the backup when you reinstall an app.
- **Factory data reset:** Erase all your information from the phone, and return the settings to the factory defaults. All data will be erased, and cannot be recovered. A factory data reset also erases the key for decrypting files stored on an optional installed memory card, so files on the card cannot be used after the reset.

Location Services Settings

Control apps' access to your location, and configure location sources.

Some apps may require one or more location services be turned On for full app functionality.

GPS signals may be affected by your surroundings, including:

- Buildings
- Tunnels or underground structures
- Weather conditions
- High-voltage or electromagnetic fields
- Tinted windows

Note: E911 location service is standard on all mobile phones, to allow sharing of GPS information with emergency personnel when you make a call to emergency services, such as 911.

1. Press  and then tap  > **Settings** > **More**.
2. Tap **Location services** to configure options:
 - **Access to my location:** Tap the **ON/OFF** switch to turn location services On or Off. When On, you are allowing Google's location service to collect anonymous location data. Some data may be stored on your device, and collection may occur even when no apps are running.
 - **Location sources:** When Access to my location is turned On, select sources for location information.
 - **Use GPS satellites:** When enabled, your phone obtains location information from GPS satellites.
 - **Use wireless networks:** When enabled, your phone obtains location information from Wi-Fi and/or wireless networks.

Security Settings

You can encrypt accounts, settings, downloaded apps and their data, media, and other files. After encryption, you must enter the PIN or password you set each time you turn on your phone. You can also encrypt information stored on an optional installed memory card (not included).

Encryption may take an hour or more to complete. Start with a charged battery, and keep the device on the charger until encryption is complete. Interrupting the encryption process may result in the loss of some or all data.

1. Press  and then tap  > **Settings** > **More**.
2. Tap **Security**, and then tap an option:
 - **Encrypt device:** Tap **Set screen lock type** to start, and then follow the prompts to encrypt information.
 - **Encrypt external SD card:** Tap **Set screen lock type** to start, and then follow the prompts to encrypt information.

Passwords

Use the Make passwords visible setting to briefly display password characters as you enter them into password fields.

1. Press  and then tap  > **Settings** > **More**.

2. Tap **Security**, and then tap the check box beside Make passwords visible to enable or disable the setting.

Device Administration

Some applications, such as Corporate email, may require you allow access to your device by device administrators in certain circumstances, such as if your device is lost or stolen.

Some features a device administrator might control include:

- Setting the number of failed password attempts before the device is restored to factory settings.
 - Automatically locking the device.
 - Restoring factory settings on the device.
1. Press  and then tap  > **Settings** > **More**.
 2. Tap **Security**, and then tap an option:
 - **Device administrators**: Tap to view, add, or remove device administrators.
 - **Unknown sources**: Tap the check box to enable or disable your phone's ability to install apps from sources other than Google Play Store.
 - **Verify apps**: Tap the check box to enable or disable a warning before installing apps that may cause harm.
 - **Change security level**: Choose a security level for device administration.

Security Update Service

Choose options for updating your phone's security policy.

1. Press  and then tap  > **Settings** > **More**.
2. Tap **Security**, and then tap an option:
 - **Security policy updates**: When enabled, your phone will automatically check for changes to the security policy and download any updates, to improve security and service.
 - **Send security reports**: When enabled, your phone will send security reports to Samsung when it is connected to a Wi-Fi network.

Credential Storage

You can install credentials from an optional installed memory card (not included), and use the Credential storage settings to allow applications to access the security certificates and other credentials.

1. Press  and then tap  > **Settings** > **More**.
2. Tap **Security**, and then tap an option:
 - **Storage type**: Displays the type of credentials stored (not configurable).
 - **Trusted credentials**: Tap to view credentials you've installed.
 - **Install from device storage**: Tap to install encrypted certificates from an optional installed memory card (not included).
 - **Clear credentials**: Tap to clear stored credentials and reset the password (only available when credentials are installed).

Application Manager Settings

You can download and install applications from the Google Play Store or Samsung Apps, or create applications using the Android SDK and install them on your device. Use Application manager to manage applications on your device.

Warning: Because this device can be configured with system software not provided by or supported by Google or any other company, end-users operate these devices at their own risk.

1. Press  and then tap  > **Settings** > **More**.
2. Tap **Application manager**, and then tap **Downloaded**, **SD card**, **Running**, or **All** to view the status of apps and services. Tap an app or service for more information, and for app options, such as stopping and uninstalling.

Battery Settings

See what's using battery power.

1. Press  and then tap  > **Settings** > **More**.
2. Tap **Battery** to view battery usage for apps and services. Tap an item for more information, or to configure options for managing power use.

Storage Settings

Manage the use of memory resources in your phone's Device memory, and on an optional installed memory card (not included).

1. Press  and then tap  > **Settings** > **More**.
2. Tap **Storage** to view information about memory usage, and for other options:
 - **Device memory**: View memory usage for the different types of information stored on your phone's memory. Tap an item for more information.

- **SD card:** View memory usage for the different types of information stored on an optional installed memory card (not included).
 - **Mount SD card:** Prepare an optional installed memory card for use as storage in the phone. This option is only available if an optional memory card is installed, and is not already mounted. Usually, your phone mounts a memory card as soon as you install it.
 - **Unmount SD card:** Prepare an optional installed memory card for safe removal or formatting.
 - **Format SD card:** Permanently remove all content from an optional installed memory card. After formatting, the content cannot be retrieved.

Date and Time Settings

Your phone obtains its time and date information by using the network-provided date, time, and time zone. These values can be manually altered.

1. Press  and then tap  > **Settings** > **More**.
2. Tap **Date and time** to configure settings:
 - **Automatic date and time:** When enabled, the device takes date and time updates from the wireless network.
 - **Set date:** Enter the current date (only available when Automatic date and time is disabled).
 - **Set time:** Enter the current time (only available when the Automatic setting is disabled).
 - **Automatic time zone:** When enabled, the device takes the time zone from the wireless network.
 - **Select time zone:** Choose your local time zone (only available when the Automatic setting is disabled).
 - **Use 24-hour format:** Set the format for time displays.
 - **Select date format:** Set the format for date displays.

Activate This Device

Connect to the network and activate your device. If your device is already activated, use this option to view information about your plan and usage.

1. Press  and then tap  > **Settings** > **More**.

2. Tap **Activate this device**, and then follow the prompts to activate your device on the network.

System Update Settings

Use System update options to update your phone's internal software.

1. Press  and then tap  > **Settings** > **More**.
2. Tap **System Update** to use these options:
 - **Update PRL:** Download and the latest Preferred Roaming List (PRL), used by your phone to access the network.
 - **Update Profile:** Update the user profile related to your wireless service account. If you choose to change your user name online, use this option to update the user name on your phone.
 - **Update Samsung Software:** Upgrade to the latest software available for your device.
 - **Update Firmware:** Update your phone's firmware. Follow the prompts to download and install the update.

About Device Settings

The About Device menu lets you access important phone information about your phone.

1. Press  and then tap  > **Settings** > **More**.
2. Tap **About device**, and then tap items for more details:
 - **Status:** View information about your device's current status.
 - **Legal information:** Display open source licenses, configure license settings, including your DivX® VOD registration, and view the privacy alert and Google info.
 - **Device name:** View your device's name, and enter a new name if desired.
 - **Model number:** View your device's model number.
 - **Android version:** View the firmware version of your device.
 - **Baseband version:** View the baseband version of your device.
 - **Kernel version:** View the kernel version of your device.
 - **Build number:** View the build number of your device.
 - **SE for Android status:** View information about your phone's Android status.

- **Hardware version:** View the hardware version of your device.

Copyright Information

©2013 Samsung Telecommunications America, LLC.

BOOST and BOOSTMOBILE and logo are trademarks of Boost.

Other marks are trademarks of their respective owners.

The actual available capacity of the internal memory is less than the specified capacity because the operating system and default applications occupy part of the memory. The available capacity may change when you upgrade the device.

Index

- 4G Services, 66
- About Device, 135
- Accessibility, 121
 - Settings, 121
- Accounts, 42
 - Email, 44
 - Gmail, 42
 - Google, 42
 - Social Network, 55
- Accounts and Sync, 129
- Activation, 3, 134
- Airplane Mode, 99
- Alarm and Timer, 87
- Answer a Call, 29
- Application Manager, 133
- Apps, 57
- Back Key, 9
- Battery
 - Install, 1
- Bluetooth, 67, 82
 - Connect to a Car Kit, 68
 - Receive Information, 71
 - Send Information, 69
 - Turn On or Off, 68
 - Unpair, 69
- Brightness, 107
- Browser, 65
- Calculator, 85
- Calendar, 85
- Camera, 9, 73
- Clock, 87
- Contacts, 36
 - Accessing Contacts, 36
 - Add, 36
 - Adding Entries to Your Favorites, 39
 - Edit, 37
 - Save a Number, 37
 - Share, 41
- Contacts Groups, 39
 - Adding Contacts, 40
 - Creating a New Group, 40
 - Sending a Message to a Group, 40
- Corporate Email
 - Creation, 44, 45
- Data Services, 65
- Data Usage, 98
- Date and Time, 134
- Display Settings, 105
- DivX, 60
- Downloads, 87
- Drag, 14
- Dropbox, 87
- Earpiece, 8
- Editing Text, 25
- Email, 44
 - Compose, 45
 - Microsoft Exchange Accounts, 44
- Email Message
 - Make a call from, 28
- Emergency Numbers, 28
- Enhanced 911 (E911), 29
- Enter Text, 22
- Extended Home Screen, 20
- Flash, 9
- Flick, 15
- Flipboard, 55
- Front camera, 8
- Gestures, 11
- Gmail, 42
- Google
 - Google+, 56
 - Maps, 64
 - Play Books, 63
 - Play Magazines, 63
 - Play Movies &TV, 63
 - Play Music, 63
 - Search, 89
 - Voice Typing, 23
 - Wallet, 93
- Google Play Store, 61
 - Install an App, 61
 - Wallet Account, 62

- Google Voice Typing, 122
 - Configuring, 24
 - Using, 24
- Google+, 56, 82
- Headset Jack, 9
- Help, 89
- Home Key, 9
- Home Screen, 19
 - Extended, 20
 - Shortcuts, 19
 - Widgets, 20
- In-call Options, 33
- Incoming Call
 - Answer, 29
- Keyboard, 122, 124
 - Samsung, 122, 124
 - Touchscreen, 22
- Language and Input, 122
- LED Indicator, 109
- Location Services, 130
- Maps, 64
- Menu Key, 9
- Messaging, 42, 50
 - Options, 53
- Microphones, 9
- microSD Card, 6
- MMS Messaging, 50
- Mobile Networks, 99
- Music
 - Google Play Music, 63
 - Music Player, 63
- Music Player, 63
- My Files, 89
- Navigation
 - Maps, 64
- Nearby Devices, 101
- NFC, 100
- Notification Icons, 22
- Phone, 27
 - External features and buttons, 1
 - Layout, 8
 - Navigation, 11
- Phone Calls
 - 3-way Calling, 32
 - Answer an Incoming Call, 29
 - Call a Number in a Text Message, 28
 - Call Forwarding, 32
 - Call from Contacts, 27
 - Call from Logs, 27
 - Call Waiting, 31
 - Caller ID, 31
 - Dialing Options, 31
 - Emergency numbers, 28
 - From email messages, 28
 - From text messages, 28
 - Make calls, 27
 - Mute the Ringing Sound, 29
 - Receive, 29
 - Reject a Call with a Text Message, 30
 - Reject an Incoming Call, 29
 - Speed Dialing, 33
 - Using phone dialpad, 27
 - Using recent calls, 27
- Picasa, 83
- Pinch, 17
- Play Books, 63
- Play Magazines, 63
- Play Movies & TV, 63
- Play Music, 63
- Power Key, 9
- Proximity sensor, 8
- Recent Calls, 34
 - Clear, 35
 - Make call from, 27
 - Options, 34
 - View, 34
 - View Logs, 34
- Rotate, 16
- S Beam, 100
- S Memo, 90
- S Suggest, 92
- S Voice, 92
- Samsung Keyboard, 122, 124
- SD Card, 6
 - Format, 7
 - Insert, 6
 - Remove, 7
 - Unmount, 7

- View Memory, 7
- Search (Google), 89
- Security
 - Screen Lock, 102
- Settings, 94
 - Accessibility, 121
 - Accounts and Sync, 129
 - Data Usage, 98
 - Date and Time, 134
 - Display, 105
 - Language and Input, 122
 - LED Indicator, 109
 - Sound, 109
 - Storage, 133
 - Wallpaper, 105
 - Wi-Fi, 94
- Setup Application, 5
- Slide, 13
- SMS
 - Messaging, 50
- Social Network Accounts, 55
- Sound
 - Settings, 109
- Speaker, 9
- Spread, 17
- Status Bar, 21
- Status Icons, 21
- Storage
 - Settings, 133
- Swipe, 13
- Text Editing, 25
- Text Entry, 22
- Text Input
 - Methods, 23
- Text Message
 - Make a call from, 28
- Text Messaging, 50
- Text-to-Speech, 126
- Tools, 85
- Touch, 11
- Touch and Hold, 12
- Touchscreen
 - Keyboard, 22
 - Turn off, 10
 - Turn on, 10
- Typing, 22
- USB Charger/Accessory port, 9
- Video, 73
- Video Player, 83
- Videos
 - Record, 76
 - Sharing, 81
- Visual Voicemail, 30
- Voice Recorder, 93
- Voice Typing, 23
 - Configuring, 24
 - Using, 24
- Voicemail, 30
 - Notification, 30
 - Retrieve Your Voicemail Messages, 30
 - Setup, 6
 - Visual, 30
- Volume, 109
- VPN, 71, 99
- VPN Client, 93
- Wallet, 93
- Wallpaper
 - Settings, 105
- Web, 65
- Wi-Fi, 66
 - Settings, 94
- YouTube, 56, 83
- Zoom, 17